


JUMO dTRANS pH 02

Transmitter/controller for pH, redox,
NH₃, temperature and standard signals
Type 202551



B 202551.0
Operation Instructions



**WARNING:**

A sudden malfunction of the instrument, or one of the sensors connected to it, could potentially result in dangerous, overdosing! Suitable preventive measures must be in place to prevent this from happening.

**Note:**

Please read these Operating Instructions before placing the instrument in operation. Keep the manual in a place which is accessible to all users at all times.

**Resetting the brightness of the LC display:**

If the brightness setting has been adjusted so that the display text is no longer legible, the basic setting can be restored as follows:

- * Switch off the supply voltage.
- * Switch on the supply voltage and immediately press and hold the ▼ and ▲ keys simultaneously.

To set the operator language:

- * Press the EXIT key for longer than 3 seconds.
 - * Select the appropriate language with the ▼ and ▲ keys.
 - * Briefly press the PGM key.
-

Content

1	Typographical conventions	8
1.1	Warning signs	8
1.2	Reference signs	8
2	Description	9
3	Instrument identification	11
3.1	Nameplate	11
3.2	Type designation	11
3.3	Accessories (included in delivery)	13
3.4	Accessories (optional)	13
4	Assembly	14
4.1	General	14
4.2	Dimensions	14
5	Installation	15
5.1	Installation instructions	15
5.2	Electrical isolation	16
5.3	Connection	17
6	Operation	21
6.1	Controls	21
6.2	Display	22
6.3	Principle of operation	23
6.4	Measuring mode	26
6.5	Input/output information	27
6.6	User level	32
6.7	Administrator level	33
6.8	MANUAL mode / Simulation mode	35
6.9	HOLD mode	37
7	Commissioning	40
7.1	Getting started	40
7.2	Setting examples	41
8	Calibrating a pH measurement chain	46
8.1	Notes	46
8.2	General information	46
8.3	Zero point (1-point) calibration	48
8.4	2-point calibration	49

Content

8.5	3-point calibration	51
8.6	pH Antimony measurement chain	54
8.7	ISFET pH combination electrodes	54
9	Calibrating a redox measurement chain	55
9.1	Notes	55
9.2	General information	55
9.3	Zero-point calibration (one-point offset calibration)	57
9.4	2-point calibration	58
10	Calibrating an ammonia measuring cell	60
10.1	Notes	60
10.2	General information	60
10.3	Zero point (1-point) calibration	61
11	Calibrating a sensor with a standard signal	63
11.1	General information	63
11.2	Linear operating mode	65
11.3	pH operating mode	69
11.4	Conductivity operating mode	70
11.5	Concentration operating mode	76
11.6	Chlorine measurement operating mode, pH-compensated	77
12	Calibration logbook	79
12.1	General information	79
13	Controller	81
13.1	General information	81
13.2	Controller functions	81
13.3	Software controllers and outputs	82
13.4	Configuration of higher order controllers	84
13.5	Parameter sets	84
13.6	Sample configurations	85
14	Setup program	88
14.1	Configurable parameters	88
14.2	Documenting the instrument configuration	89
14.3	Special features for "Datalogger"	90
15	Eliminating errors and faults	92

Content

16	Technical data	94
16.1	Inputs (main board)	94
16.2	Resistance thermometer inputs (optional board)	94
16.3	Standard signals inputs (optional board)	94
16.4	Temperature compensation	94
16.5	Measuring circuit monitoring	94
16.6	Impedance measurement	95
16.7	Binary input	95
16.8	Controller	95
16.9	Outputs	95
16.10	Display	95
16.11	Electrical data	96
16.12	Enclosure	96
16.13	Interface	96
16.14	Approvals/marks of conformity	96
17	Retrofitting optional boards	97
18	Appendix	100
18.1	Glossary	100
18.2	Parameters of the User level	110

Index

1-point calibration - ammonia 61
1-point calibration - pH 48
2-point calibration 100
2-point calibration - pH 49
3-point calibration - pH 51
3-point calibration . 101

A

Accessories 13
Administrator 33
Asymmetrical connection 107–109

B

Basic setting 33
Binary inputs and outputs
 States 30

C

Calibration
 Ammonia, 1-point 61
 Ammonia, zero point 61
 Antimony 54
 ISFET 54
 Logbook 79
 pH ISFET 54
 pH, 2-point 49
 pH, antimony 54
 Redox, one-point 57
 Redox, zero-point 57
 Standard signal 63
 Standard signal, options 64
Calibration release 35
Configurable parameters 88
Controller
 "Higher order" switching functions 81
 "Simple" switching functions 81
 General information 81
 Parameter sets 84
Controller functions 81
Controllers
 Configuration of "higher order" controllers 84
 Setting example, limit monitoring 85
 Setting example, pulse length output 86
Customer settings 110

D

Datalogger
 Special features 90
Date of manufacture 11

Delete 35
Display 22

E

Electrical isolation 16

F

Factory settings 110

G

Getting started 40

H

HOLD mode 37

I

Info
 Device 32
 Hardware 31
Installation position 14
ISFET sensor 109

K

Key combinations 27

L

Limit functions 101

M

Manual 31
MANUAL mode 35
 Analog outputs 37
 Binary outputs 37
 Controller 36
 Deactivation 39
 Switching outputs 36
Manual mode overview 31
Menu
 Customized 28
Min/max values 28–29
Mounting location 14

O

Output 29

Optional inputs

 Current values 30

Output level display 29

P

Parameter overview 110

Password 33

Principle 23

Principle of operation 27

R

Rapid access 27

Reference signs 8

S

Setting example

 pH difference measurement 43

 pH measurement 41

Setup program 88

Simulation mode 35

Simulation of binary outputs 37

States 30

Sunlight 14

T

Temperature compensation 107

U

User 32

User data 28

W

Warning signs 8

Wash timer 109

Washing contact 109

Z

Zero point calibration 100

1 Typographical conventions

1.1 Warning signs



Danger

This symbol is used when there may be **danger to personnel** if the instructions are ignored or not followed correctly!



Caution

This symbol is used when there may be **damage to equipment or data** if the instructions are ignored or not followed correctly!

1.2 Reference signs



Note

This symbol is used to draw your **special attention** to a remark.

abc¹

Footnote

Footnotes are remarks that **refer to specific points** in the text. Footnotes consist of two parts:

A marker in the text and the footnote text.

The markers in the text are arranged as consecutive superscript numbers.

*

Instruction

This symbol indicates the description of an **action to be performed**.

The individual steps are marked by this asterisk.

Example:

* Briefly press the  key.

2 Description


Inputs/outputs

In addition to the main input (pH/redox) and the secondary input (temperature compensation), the basic instrument alone has two binary inputs, two relays, one power supply for external sensors and a setup interface.

Input signals can be shown as numbers or as a bar graph on the graphic display. Parameters are displayed in plain text for easily comprehensible and reliable operation.

Optional

Three further slots can be fitted with extensive additional configurable inputs and outputs and interfaces.



Application

The instrument is suitable, for example, for displaying, measuring and controlling:

- pH value and/or redox potential.
- Free chlorine, chlorine dioxide, ozone, hydrogen peroxide and peracetic acid, in combination with sensors as per data sheet 202630.
- (Hydrostatic) liquid levels with 2-wire transmitters (level probes) as per data sheet 40.2090 or data sheet 40.4390.
- Flow rate in conjunction with transmitters as per data sheet 40.6010.
- Two temperature measuring points.
- Most sensors and transmitters that output standard signals (0 - 10 V or 0(4) - 20 mA).

Because temperature measurement is integrated, temperature compensation takes place quickly and precisely, which is particularly important for many analytical measurements.

Key features

- Display: mg/l, pH, mV, $\mu\text{S/cm}$, etc. Special settings are also possible with the setup program
- Configurable display text (operator level)
- Alarm text with color change
- A choice of display visualizations: large numbers, bar graph or tendency

2 Description

- (trend) display
- Four limit controllers
- Integrated calibration routines: with 1, 2 and 3 points
- Math and logic module (optional)
- Calibration logbook
- Three optional slots
- Selectable languages: English, German, French, etc.
- Setup program provides: convenient programming, system documentation
- RS422/485 interface (optional)
- PROFIBUS-DP interface (optional)

3.1 Nameplate

on the transmitter

JUMO GmbH & Co. KG	JUMO dTRANS pH 02	VARTN: 20/00545848
Typ: 202551/01-8-1-4-0-00-23/000	Fulda, Germany	
F No.: 0123457 01 0 1122 0001	www.jumo.net	
~ AC 110..240 V -15%/+10%	? 13VA	



The date of manufacture is encoded in the "F No." (serial number):

1122 means year of manufacture 2011 / calendar week 22

3.2 Type designation

(1) Basic type

202551 JUMO dTRANS pH 02
Transmitter/controller

(2) Basic type extension

01 In the panel enclosure
05 In the surface-mounted enclosure

(3) Version

8 Standard with factory setting
9 Programming to customer specification

(4) Operating language¹

01 German
02 English
03 French
04 Dutch
05 Russian
06 Italian
07 Hungarian
08 Czech
09 Swedish
10 Polish
13 Portuguese
14 Spanish
16 Rumanian

3 Instrument identification

(5) Optional slot 1

- 0 Not used
- 1 Analog input (universal)
- 2 Relay (1x changeover)
- 3 Relay (2x normally open)
- 4 Analog output
- 5 Two MosFET semiconductor switches
- 6 Semiconductor relay 1 A
- 7 Supply voltage output +/- 5 V DC (e.g. for ISFET)
- 8 Supply voltage output 12 V DC (e.g. for inductive proximity switch)

(6) Optional slot 2

- 0 Not used
- 1 Analog input (universal)
- 2 Relay (1x changeover)
- 4 Analog output
- 5 Two MosFET semiconductor switches
- 6 Semiconductor relay 1 A
- 7 Supply voltage output +/- 5 V DC (e.g. for ISFET)
- 8 Supply voltage output 12 V DC (e.g. for inductive proximity switch)

(7) Optional slot 3

- 00 Not used
- 01 Analog input (universal)
- 02 Relay (1x changeover)
- 03 Relay (2x normally open)
- 04 Analog output
- 05 Two MosFET semiconductor switches
- 06 Semiconductor relay 1 A
- 07 Supply voltage output +/- 5 V DC (e.g. for ISFET)
- 08 Supply voltage output 12 V DC (e.g. for inductive proximity switch)
- 10 RS485 interface
- 11 Data logger with interface RS485²
- 12 Profibus DP interface

(8) Power supply

- 23 110 - 230 V AC, +10% / -15%, 48 - 63 Hz
- 25 20 - 30 V AC/DC, 48 - 63 Hz

(9) Extra codes³

- 000 None

¹ The only way to read files is with the PC setup software!

² List extra codes in sequence, separated by commas.

	(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)	(9)	
Order code										...
Sample order	202551	/ 01	- 8	- 01	- 2	- 2	- 04	- 23	/ 000	

3 Instrument identification

3.3 Accessories (included in delivery)

4 x fastening elements, complete¹

3 x CON plug-in link¹

3 x jumper wire²

1 x seal for panel¹

1 x fastening elements, complete²

- 1 x DIN rail fastening left

- 1 x DIN rail fastening right

- 3 x wall mount

- 3 x fastening screw

¹ For basic type extension 01 only (in the panel enclosure)

² For basic type extension 05 only (in the surface-mounted enclosure)

3.4 Accessories (optional)

Type	Sales No.
Holder for C rail	70/00375749
Dummy cover 96mm x 48mm	70/00069680
Pipe mounting set	20/00398162
Weather protection roof complete for basic type extension 05	20/00401174
PC setup software	20/00560380
PC interface cable including USB/TTL converter and two adapters (USB connecting cable)	70/00456352


Optional board	Code	Sales No.
Analog input (universal)	1	70/00442785
Relay (1 x changeover)	2	70/00442786
Relay (2 x NO)	3	70/00442787
Analog output	4	70/00442788
Two MosFET semiconductor switches	5	20/00566677
Semiconductor relay 1 A	6	70/00442790
Supply voltage output +/- 5 V DC (e.g. for ISFET)	7	20/00566681
Supply voltage output 12 V DC (e.g. for inductive proximity switch)	8	20/00566682
Interface - RS422/485	10	70/00442782
Datalogger with RS485 interface	11	20/00566678
Profibus-DP interface	12	20/00566679

4 Assembly

4.1 General

Mounting location	Find a location that ensures easy accessibility for the later calibration.
	The fastening must be secure and must ensure low vibration for the instrument.
	Avoid direct sunlight!
Installation position	Permissible ambient temperature at the installation location: -10 - 55°C with max. 95% rel. humidity, no condensation.
	The instrument can be mounted in any position.

4.2 Dimensions



Close mounting

Minimum spacing of panel cutouts	Horizontal	Vertical
Without setup connector:	30mm	11mm
With setup connector (see arrow):	65mm	11mm

5.1 Installation instructions



The electrical connection must only be performed by qualified personnel!


- ☐ The choice of cable, the installation and the electrical connection must conform to the requirements of VDE 0100 "Regulations on the Installation of Power Circuits with Nominal Voltages below 1000 V" and the relevant local regulations
- ☐ If contact with live parts is possible when working on the device, it must be completely disconnected from the electrical supply.
- ☐ The load circuits must be fused for the maximum load currents in each case to prevent the relay contacts from becoming welded in the event of a short circuit.
- ☐ Electromagnetic compatibility meets the requirements of EN 61326.
- ☐ Lay the input, output, and supply lines so they are physically separated from each other and are not parallel.
- ☐ Use twisted and shielded probe cables. If possible, do not lay these cables close to components or cables through which current is flowing. Ground the shielding at one end.
- ☐ The probe cables must have an uninterrupted run (do not route them via terminal blocks or similar arrangements).
- ☐ No other consumers can be connected to the power terminals of the instrument.
- ☐ The instrument is not suitable for installation in areas with an explosion hazard.
- ☐ Apart from faulty installation, incorrect settings on the instrument may also affect the proper functioning of the subsequent process or lead to damage. You should therefore always provide safety equipment that is independent of the instrument and it should only be possible for qualified personnel to make settings.

Mounting information for conductor cross-sections and ferrules

Ferrule	Conductor cross-section		Minimum length of ferrule or stripping
	Minimum	Maximum	
Without ferrule	0.34 mm ² .	2.5 mm ² .	10 mm (stripping)
Without collar	0.25 mm	2.5 mm ² .	10 mm
With collar up to 1.5 mm ²	0.25 mm ² .	1.5 mm ² .	10 mm
Twin, with collar	0.25 mm ² .	1.5 mm ² .	12 mm


5 Installation

5.2 Electrical isolation



5.3 Connection

5.3.1 Terminal assignment











(1)	Row 1	(a)	Option 1	(b)	Option 2	(c)	Option 3
(2)	Row 2	Main input board (pH / redox / temperature / standard signal)					
(3)	Row 3	PSU board (power supply / 2x relays)					

5.3.2 Optional board (row 1, slot a, b or c)

Function	Symbol	Terminal for slot (a)	Terminal for slot (b)	Terminal for slot (c)
Analog input				
Temperature sensor in a two-wire circuit Pt100 or Pt1000		2 4	6 8	10 12
Temperature sensor in a three-wire circuit Pt100 or Pt1000		2 3 4	6 7 8	10 11 12
Resistance transmitter		2 3 4	6 7 8	10 11 12
Electrical current		3 4	7 8	11 12

5 Installation

Function	Symbol	Terminal for slot (a)	Terminal for slot (b)	Terminal for slot (c)
Voltage 0(2) - 10 V		1 2	5 6	9 10
Voltage 0 - 1 V		2 3	6 7	10 11
Continuous output				
Current or voltage		2 3	6 7	10 11
Modbus interface				
RS422		1 2 3 4	5 6 7 8	9 10 11 12
RS485		3 4	7 8	11 12
Profibus interface				
		1 2 3 4	5 6 7 8	9 10 11 12
Data logger interface				
RS485		2 3	6 7	10 11
Relay (1x changeover)				
		K3 1 2 3	K4 5 6 7	K5 9 10 11
Relay (2x NO, common pin)				
		K3 1 2 K6 3		K5 9 10 K8 11
Triac (1 A)				
		K3 2 3	K4 6 7	K5 10 11
Foto-MOS relay (0.2 A)				
		K3 1 2	K4 5 6	K5 9 10
		K6 3 4	K7 7 8	K8 11 12



5 Installation

Function	Symbol	Terminal for slot (a)	Terminal for slot (b)	Terminal for slot (c)
Power supply for ISFET sensor				
DC +/- 5 V		1	5	9
GND		2	6	10
		3	7	11
		4	8	12
DC +12 V		1	5	9
GND		2	6	10




5.3.3 Main board (row 2)

Function	Symbol	Terminal
Power supply for ISFET sensor		
DC +/- 4.85 V		11
GND		10
		15
Standard signal input for electrical current		
0(4) - 20 mA		3
		4
Standard signal input for voltage		
0(2) - 10 V or 10 - 0(2) V		1
		4
Temperature sensor in a two-wire circuit		
Pt100 or Pt1000		2
		3
		4
Temperature sensor in a three-wire circuit		
Pt100 or Pt1000		2
		3
		4
Resistance transmitter		
		4
		3
		2
pH/redox electrode		
Shield for pH (with triaxial cable only!)		6
Glass/metal electrode		7
Reference electrode		8
Liquid potential (LP) With asymmetrical connection, bridge between terminal 8 and 9 With symmetrical connection, LP on terminal 9		9

5 Installation

Binary inputs		
Binary input 1		12+ 14
Binary input 2		13+ 14

5.3.4 PSU board (row 3)


Function	Symbol	Terminal
Power supply for JUMO dTRANS 02		
Power supply: AC 110 - 240 V		1 L1 (L+)
Power supply: AC/DC 20 - 30 V		2 N (L-)
n.c.		4 5 6
Supply voltage for external 2-wire transmitter		
24 V DC (-15 / +20%)		8 L +
		9 L -
Relay 1		
Switching output K1 (floating)		11 12 13
Relay 2		
Switching output K2 (floating)		15 16 17



Operation via the instrument keypad is described below.

Instrument operation via the optional set-up program, See section 14 "Setup program", page 88.

6.1 Controls




- (1) Measurement unit
- (2) Temperature
- (3) Operating mode
- (4) Measured value
- (5)  key Increase numerical value / Forward selection
- (6)  key Decrease numerical value / Forward selection
- (7)  key Change level / Forward selection / Confirm selection
- (8)  key Cancel entry / Exit level

6 Operation

6.2 Display

6.2.1 Measuring mode (normal display)

Example



- (1) Binary output (relay) K1 is active
- (2) Binary output (relay) K2 is active
- (3) Binary input is active
- (4) Keypad is locked
- (5) Instrument status
 - ALARM (flashing): Broken sensor or overrange, etc.
 - AL R1: Controller monitoring alarm from controller channel 1
 - AL R2: Controller monitoring alarm from controller channel 2
 - CALIB: Calibration mode active
 - CALIB (flashing): Calibration timer elapsed
- (6) Output mode
 - MAN.: Manual mode and/or simulation mode active
 - HOLD: Hold mode active
- (7) Top display
 - Measured value and unit of the variable set by parameter "Top display"
- (8) Bottom display
 - Measured value and unit of the variable set by parameter "Bottom display"
- (9) Operating mode
 - MEASURING: Standard measuring mode is active



To return to measuring mode (MEASURING):
Press the  key or wait for a "timeout".

6.3 Principle of operation

6.3.1 Operation in levels

	See page
Measurement mode	
Normal display	26
Min/max values of the main input	28
Min/max values of the optional inputs	29
Output display	29
Current values of the main input	29
Current values of the input options	30
Current values of the math channels	30
States of the binary inputs and outputs	30
Manual mode overview	31
Hardware information	31
Instrument information	32
User data	89
Calibration (depending on the basic setting)	46, 55, 60, 63
Manual mode / simulation	35
Hold mode	37
Main menu	
User level	32
Input pH/redox	110
Input temperature	110
Optional inputs	111
Analog input 1, 2, 3	
Binary inputs	112
Binary input 1, 2	
Controllers	113
Controller 1	
Parameter set 1, 2	
Configuration	
Controller 2	
Parameter set 1, 2	
Configuration	
Controller special functions	115
Limit value control	115
Limit value 1, 2, 3	
Binary outputs	112
Binary output 1, 2, 3, ... 8	
Analog outputs	117
Analog output 1, 2, 3	
Interface	118
Wash timer	118
Datalogger	118

6 Operation

Display	119
Administrator level (password)	33
Parameter level	33
Parameters as above for "User level"	
Release level	33
Parameters as above for "User level"	
Basic setting	33
Calibration level	35
Main input (depending on the basic setting)	
Zero point	
2-point	
3-point	
Optional input 1, 2, 3	
Temperature coefficient, linear	
Temperature coefficient, curve	
Relative cell constant	
Zero point	
Limit point	
2-point	
Calibration release	35
Main input (depending on the basic setting)	
Temperature coefficient, linear	
Temperature coefficient, curve	
Relative cell constant	
Zero point	
Limit point	
2-point	
3-point	
K factor	
Optional input 1, 2, 3	
Temperature coefficient, linear	
Temperature coefficient, curve	
Relative cell constant	
Zero point	
Limit point	
2-point	
3-point	
Delete min/max values	35
Main input	
Optional input 1, 2, 3	
Delete logbook	35
Main input	
Optional input 1, 2, 3	
Delete daily batch	35

	Delete total batch	35
	Calibration level	46, 55, 60
	Main input	
	Zero point	
	2-point	
	3-point	
	Optional input 1, 2, 3	111
	Temperature coefficient, linear	
	Temperature coefficient, curve	
	Relative cell constant	
	Zero point	
	Limit point	
	2-point	
	Calibration logbook	79
	Main input	
	Optional input 1, 2, 3	
	Instrument information	32

6 Operation

6.4 Measuring mode



Different display types can be configured, See "Display of measured values STANDARD" page 102.

To return to measuring mode:
press the EXIT key or wait for a "timeout".

Measurements with "out of range" are ignored.

The min./max. value memory can be reset:
Administrator level / Delete min/max.


When the basic setting is changed, the min and max values are deleted.

6.4.1 Normal display

Visualization


The following are displayed in measuring mode:

- Analog input signal
- Unit (for example pH)
- Temperature of the sample medium




- (1) MEASURING -> Measuring mode
- (2) 25.0°C -> Temperature of the sample medium
- (3) 7.70 pH -> Measurement value calculated from the standard signal at the input

6.5 Input/output information



6 Operation



¹ Only if released

6.5.1 User data

SP 1 Reservoir II
7.03 pH

Up to 8 parameters that are frequently changed by the user can be combined in the user level under "User data" (via setup program only).

Activating the display

The instrument is in measuring mode (normal display)

- * Briefly press the key.
- * Select the required "quick setting" with the and .

Editing

- * Briefly press the key.
- * Edit the setting with the and .

6.5.2 Min/max values of the main input

MIN/MAX MAIN INP.
1: 5.03 8.52 pH
T: 25.0 25.0 °C

Activating the display

The instrument is in measuring mode (normal display)

- * Briefly press the or key (several times if necessary).
Minimum and maximum values of the main value "1:" (pH, mV, %, ppm) and

temperature "T:" are displayed.

The extreme values of the main measurement variable and the temperature are **not** mutually assigned (for example not 5.03 pH for 25.0°C).

6.5.3 Min/max values of the optional inputs

MIN/MAX OPT. INP.		
1:	----	----
2:	----	----
3:	0	2001

Activating the display

The instrument is in measuring mode (normal display)

- * Briefly press the ▲ or ▼ key (several times if necessary).
Minimum and maximum values of the optional inputs (1, 2 and 3) are displayed

6.5.4 Ooutput level

OUTPUT		
CTRL. 1		0 %
CTRL. 2		100 %

Activating the display

The instrument is in measuring mode (normal display)

- * Briefly press the ▲ or ▼ key (several times if necessary).
The current output levels of the controller outputs.

6.5.5 Current values of the main entries

MAIN VAL.		6.99 pH
TEMP. INP.		25.0 °C

Activating the display

The instrument is in measuring mode (normal display)

- * Briefly press the or ▼ key (several times if necessary).
The current values of the main output are displayed.

6 Operation

6.5.6 Current values of the optional entries

OPT.	IN	1	0
OPT.	IN	2	0
OPT.	IN	3	0

Activating the display

The instrument is in measuring mode (normal display)

- * Briefly press the ▲ or ▼ key (several times if necessary).
The current values of the optional inputs (1, 2 and 3) are displayed.

6.5.7 Current values of the math channels

MATHS	1	8888
MATHS	2	8888

Activating the display

The instrument is in measuring mode (normal display)

- * Briefly press the ▲ or ▼ key (several times if necessary).
The current values of the main output are displayed.

6.5.8 States of the binary inputs and outputs

OVERVIEW BIN. SIG.							
E1	0	E2	0				
K1	⊗	K2	0	K3	0	K4	0
K5	0	K6	0	K7	0	K8	0

Activating the display

The instrument is in measuring mode (normal display)

- * Briefly press the ▲ or ▼ key (several times if necessary).
The states of binary inputs E1 and E2 and of relays K1 through K8 are displayed. In the example shown here, relay K1 is active.

6.5.9 Manual mode overview

Analog outputs (optional boards)

In this example, analog outputs 2 and 3 are working normally.

```
MANUAL OVERVIEW
ANALOG INPUT 1  MAN.
ANALOG INPUT 2  ----
ANALOG INPUT 3  ----
```

Switching outputs (PSU board and optional boards)

In this example relay output 2 is in manual mode.

```
MANUAL OVERVIEW
BINARY OUTPUTS
K1 0 K2 0 K3 0 K4 0
K5 0 K6 0 K7 0 K8 0
```

The instrument is in "normal display" mode

* Briefly press the ▲ or ▼ key (several times if necessary).



Manual mode can only be displayed if at least one output is in manual mode. For example Administrator level / Parameter level / Binary outputs / Binary output 1 / Manual mode "Active" or "Simulation".

To return to measuring mode:
press the  key or wait for a "timeout".

6.5.10 Hardware info



These displays are required for phone support.

The instrument is in measuring mode (normal display)

* Press and hold the  and ▲ keys.

```
MAIN CPU 268.01.01-34
MAIN INPUT 269.01.01-04
```

Alternating display

6 Operation

OPTION 1	200.01.02
OPTION 2	
OPTION 3	193.02.01
BOOTLOADER	297.00.01

6.5.11 Device info



These displays provide an overview of fitted hardware options and the settings of inputs (helpful for troubleshooting, etc.).

- * Press the  key for longer than 3 seconds.
- * Briefly press the  or  key (several times if necessary).
- * Select Device info

ADMINISTR. -LEVEL	>
CALIBR. -LEVEL	>
CALIBR. -LOGBOOK	>
DEVICE INFO	>

- * Press the  keys.

MAIN INP.	PH/REDOX
OPTION 1:	ANALOGOUT
OPTION 2:	ANALOG IN
OPTION 3:	DATALOG.

- * Briefly press the  or  key (several times if necessary).
For further information about the inputs, press the  or  keys.

6.6 User level

All the parameters that the Administrator (See section 6.7 "Administrator level", page 33) has released can be edited at this level. All the other parameters (marked by a key ) are read only.

- * Press the  key for longer than 2 seconds.
- * Select "USER LEVEL".

USER LEVEL	>
ADMINISTR. -LEVEL	>
CALIBR. -LEVEL	>
CALIBR. -LOGBOOK	>

All possible parameters are accessed below. Depending on the configuration of a specific instrument, some of these parameters may not appear.

6.6.1 Parameters of the User level

See section 18.2 "Parameters of the User level", page 110.

6.7 Administrator level

- All the parameters can be edited at this level.
- At this level, it is also possible to define which parameters can be edited by a "normal" user (operator) and which calibrations can be performed.

To get to the Administrator level, proceed as follows:

- * Press the  key for longer than 2 seconds.
- * Use the  or  keys to select "ADMINISTR. LEVEL".
- * Use the  and  keys to enter the password 300 (factory setting).
- * Confirm the  key.

6.7.1 Parameter level

The settings that can be made here are the same as those at the User level, See "User level" page 32. As the operator (user) has administrator rights here, the parameters that are locked in the User level can now also be modified.

6.7.2 Release level

All parameters can be released (modification possible) or locked (no modification possible) for editing at operator level.

6.7.3 Basic settings


The JUMO dTRANS 02 pH has a basic setting wizard, to make it easier for the user to configure the extensive setting options of the instrument and to avoid configuration conflicts.

The basic settings are reached via ADMINISTR. LEVEL / PASSWORD / BASIC SETTING.

All the important settings are systematically polled here. At the end, once a request for conformation has been acknowledged, the instrument is initialized with the new settings. Dependent parameters are checked and adjusted.

Basic setting wizard

6 Operation



6.7.4 Calibration level

Depending on which operating mode has been configured (in the Basic setting menu), one or more of the following calibration options will be available:

- Zero point
- 2-point calibration (only with setting "pH STANDARD" and "pH ANTIMONY")
- 3-point calibration (only with setting "pH STANDARD" and "pH ANTIMONY")

6.7.5 Calibration release

Which calibration procedure may be performed directly and which may not can be configured here, See section 8.2.2 "Ways to start the calibration", page 47.

6.7.6 Delete min/max values

If required, the values can be deleted once a request for confirmation has been acknowledged.

See "Min/max values of the main input" page 28 or

See "Min/max values of the optional inputs" page 29.

6.7.7 Delete logbook

The last five calibration processes for each input are archived in the calibration logbook. If a "Datalogger" optional board is fitted, the date and time are also archived.

If necessary the logbook can be deleted after a confirmation prompt.

6.7.8 Delete daily batch

If required, the counter can be deleted once a request for confirmation has been acknowledged.

6.7.9 Delete total batch

If required, the counter can be deleted once a request for confirmation has been acknowledged.

6.8 MANUAL mode / Simulation mode

These functions can be used to set the switching outputs and analog outputs of the instrument manually to a defined state. This facilitates dry startup, troubleshooting and customer service. ▲

Simulation mode accesses the analog outputs and binary outputs **directly**. When simulation mode has been selected, MANUAL mode is **not** possible!

In MANUAL mode the settings for "higher order controllers" are taken into consideration.

6 Operation

6.8.1 MANUAL mode only via "higher order" controller functions

Select manual mode



In the factory setting of the instrument the MANUAL mode parameter is locked and can **only be activated by the administrator!**

This parameter must first be released for other users, See "Release level" page 33.

- * Set ADMINISTR. LEVEL / PARAMETER LEVEL / CONTROLLER / CTRL.SPEC. FUNCT. / MANUAL MODE "Locked, **Coding** or **Switching**.

Locked = No Manual mode, control is via device.

Coding = The outputs are active as long as the ▼ or ▲ key is pressed.

Switching = the outputs are active if the ▼ or ▲ key is pressed. If the corresponding key is pressed again, the output becomes inactive again.

Activate Manual mode

The instrument is in Display mode

- * Press the  and  keys for less than 2 seconds.
The word MANUAL appears in the status line of the display.



If the  keys (alone) are pressed for longer than 3 seconds, the instrument switches to language selection!

If the  and  keys are pressed for longer than 3 seconds, the instrument goes into HOLD mode.

Then the outputs of the instrument respond according to the default settings.

To exit HOLD mode, press the  and  keys for longer than 3 seconds.

Control is not longer via the instrument. The output level of the controllers is 0%.

Controller 1 is activated by the  key. In this case the output level of controller 1 is 100%.

Controller 2 is activated by the  key. In this case the output level of controller 2 is 100%.

Deactivation

- * Press the  key.

Control is once again through the outputs of the instrument.
The word MANUAL appears in the status line of the display.

6.8.2 Simulation of binary outputs

Activate simulation



In the factory setting of the instrument the MANUAL mode parameter is set to "No simulation" and can **only be activated by the administrator!**

This parameter must first be released for other users, See "Release level" page 33.

If a higher order switching function has been assigned to an output, Simulation mode is not possible for that output.

- * Set ADMINISTR. LEVEL / PARAMETER LEVEL / BINARY OUTPUTS / BINARY OUTPUT1(...8) "Manual mode no simulation, **Inactive** or **Active**".

No simulation = No Manual mode, control is via device.

Inactive = Relay K1 or K2 is de-energized; the word MANUAL appears in the status line of the display

Active = Relay K1 or K2 is energized; the word MANUAL appears in the status line of the display

Deactivate manual mode

No simulation = No Manual mode, control is via device.

When the instrument is in display mode, the word MANUAL disappears from the status line of the display.

6.8.3 Simulation of analog outputs via MANUAL mode

Release and activation

- * Select activation of simulation of the actual value output:
ADMINISTR. LEVEL / PARAMETER LEVEL / ANALOG OUTPUTS / ANALOG OUTPUT 1 (2, 3) / SIMULATION / ON.

With "On" the output takes on the value of the "Simulation value" parameter.

When the instrument is in display mode, the word MANUAL appears in the status line of the display.

Deactivation

- * ADMINISTR. LEVEL / PARAMETER LEVEL / ANALOG OUTPUTS / ANALOG OUTPUT 1 (2, 3) / SIMULATION / OFF.

The corresponding output of the instrument works again.

When the instrument is in display mode, the word MANUAL disappears from the status line of the display.

6.9 HOLD mode

In HOLD status the outputs take on the states programmed in the relevant parameter (controller channel, switching output or analog output).

This function can be used to "freeze" switching outputs and the analog

6 Operation

outputs of the instrument. This means the current status of the output will be retained even when the measured value changes. Control is not via the instrument.



If MANUAL mode is activated while HOLD mode is activated, MANUAL mode takes precedence and MANUAL then appears in the status line of the display! MANUAL mode can be terminated by pressing the  key. If HOLD mode is still activated (by the binary input or by keyboard), the instrument then returns to HOLD mode!

HOLD mode can be activated by pressing the key or by the binary input.

Activation by pressing key

- * Press and hold the  and  keys longer than 3 seconds. Then the outputs of the instrument respond according to the default settings. The word HOLD appears in the status line of the display.



If the  and  keys are pressed for less than 3 seconds, the instrument goes into Manual mode. Then the outputs of the instrument respond according to the default settings.

Pressing a key to deactivate HOLD mode

* Press the  and  keys for longer than 3 seconds.



If the  and  keys are pressed for less than 3 seconds, the instrument goes into Manual mode.

Then the outputs of the instrument respond according to the default settings.

Control is through the outputs of the instrument again. The word MANUAL disappears from the status line of the display.

7 Commissioning

7.1 Getting started



Some suggestions follow for configuring the instrument reliably in little time.

- * Mount the instrument, See section 4 "Assembly", page 14.
- * Install the instrument, See section 5 "Installation", page 15 ff.
- * Call up Administrator level (ADMINISTR. LEVEL).
- * Enter password 0300 (factory setting).
- * Call up PARAMETER LEVEL / DISPLAY / OPERAT. TIMEOUT.
- * Set OPERAT. TIMEOUT to 0 minutes (no timeout).
- * Leave the Display level with "EXIT"
- * Leave the Parameter level with "EXIT"
- * Select BASIC SETTING and work through all the menu items, See section 6.7.3 "Basic settings", page 33.
- * Answer "YES" to the "Reinitialize device" query
- * Configure the required additional parameters.
- * Calibrate the instrument to the sensor and sample medium,
See section 8 "Calibrating a pH measurement chain", page 46 or
See section 9 "Calibrating a redox measurement chain", page 55 or
See section 10 "Calibrating an ammonia measuring cell", page 60 or
See section 11 "Calibrating a sensor with a standard signal", page 63.


7.2 Setting examples

7.2.1 Measuring the pH value with pH combination electrode



pH measurement with automatic temperature compensation.

Layout



		Data sheet
(1)	Transmitter/controller type 202551	202551
(2)	pH combination electrode on the main board	201020
(3)	Coaxial cable	202990
(4)	Two-wire shielded cable	202990
(5)	Compensation thermometer Pt100 on the main board	201085

Electrical connection

See section 5 "Installation", page 15.

Task

Measuring range:	2 - 12 pH
Output signal:	4 - 20 mA
Temperature measurement	Pt100
Control function:	Pulse width controller
Setpoint 1:	pH 6.5
Setpoint 2:	pH 8.5

7 Commissioning

Basic setting



Start the basic settingsSee section 6.7.3 "Basic settings", page 33
Diagrammatic overview, See section "Basic setting wizard", page 33.

Sensor	pH standard
Temperature compensation source	Temperature input
Reference monitoring	Off
Glass electrode monitoring	Off
Supply frequency	50 Hz
Reinitialize device	Yes

Temperature input

Administrator level / Password / Parameter level / Temperature input
Temperature sensor Pt100

Analog output

Administrator level / Password / Parameter level / Analog outputs / Analog output 1
Signal source Main variable
Signal type 4 - 20 mA
Start of scaling 2.00 pH
End of scaling 12.00 pH

Controller settings


See section 13.6.2 "Controller with PID behavior and pulse length output", page 86.

7.2.2 pH differential measurement



Both pH measurements are automatically temperature compensated.

Layout



	Data sheet
(1) Transmitter/controller type 202551	202551
(2) pH combination electrode with 2-wire transmitter	201020
(2a) pH combination electrode on main board	201020
(3) Two-wire transmitter on optional board 1	202701
(4) Two-wire shielded cable	202990
(5) Compensation thermometer Pt100 on optional board 2	201085
(5a) Compensation thermometer Pt100 on main board	201085
(6) Coaxial cable	202990

Electrical connection

See section 5 "Installation", page 15.

Task

Measurement range (main board): 2 - 12 pH
Measurement range (optional board): 2 - 12 pH
Output signal (main board): 4 - 20 mA
Temperature measurements Pt100
Actual value for the controller: main board

7 Commissioning

Limit value control:	limit value function
Limit value 1:	pH 6.5
Limit value 2:	pH 8.5

Basic setting of main board



Start the basic settings See section 6.7.3 "Basic settings", page 33
Diagrammatic overview, See section "Basic setting wizard", page 33.

Sensor	pH standard
Temperature compensation source	Temperature input
Reference monitoring	Off
Glass electrode monitoring	Off
Supply frequency	50 Hz
Reinitialize device	Yes

Input for main board temperature

Administrator level / Password / Parameter level / Temperature input
Temperature sensor Pt100

Analog output of main board

Administrator level / Password / Parameter level / Analog outputs / Analog output 1
Signal source Main variable
Signal type 4 - 20 mA
Start of scaling 2.00 pH
End of scaling 12.00 pH

Basic setting for optional board 1

Administrator level / Password / Parameter level / Optional inputs / Analog input 1
Operating mode pH measurement
Signal type 4 - 20 mA
Start of scaling -600 mV (depending on the two-wire transmitter)
End of scaling +600 mV (depending on the two-wire transmitter)
Temperature compensation source Optional input 2

7 Commissioning

Basic setting for optional board 2

Administrator level / Password / Parameter level / Optional inputs / Analog input 2

Operating mode	Temperature
Signal type	Pt100
Connection type	2-wire

Controller settings

See section 13.6.1 "Simple limit monitoring", page 85.

8 Calibrating a pH measurement chain

8.1 Notes



During calibration, relays and analog output signals adopt their configured states!



When is calibration required?

- At regular intervals (depending on the sample medium and requirements).
- If negative values appear in the top display.
- If the top display indicates "Underrange / Overrange".

Every successfully completed calibration is documented in the calibration logbook, See section 12 "Calibration logbook", page 79.

8.2 General information

The electrical properties of all sensors vary slightly from instance to instance and also change during operation (due to deposits or wear, etc.). This causes the output signal of the sensor to change.

The transmitter uses a typical, concentration-dependent characteristic to measure ammonia with "normal" accuracy requirements. The individual properties of the sensor are taken into account here by offsetting the zero point. This considerably reduces the effort required for calibration.

The transmitter software is specially adapted for coolant monitoring.

8.2.1 Requirements

- The instrument must be supplied with voltage, See section 4 "Elektrischer Anschluss", page 13 ff.
- A combination electrode must be connected to the transmitter.



For a configuration example See section 7.2.1 "Measuring the pH value with pH combination electrode", page 41.

A pH sensor can be connected to the optional board

- connected directly to the main input or
- connected to the "Analog input (universal)" optional board via a 2-wire transmitter.

-
- "PH STANDARD" must be configured as sensor in the basic setting.
 - The instrument is in Measurement mode.

8 Calibrating a pH measurement chain

8.2.2 Ways to start the calibration



Select the input to which the pH sensor is connected.

MAIN INPUT	3
OPT. INPUT 2	3

If Calibration level is not released

- Press the  key for longer than 3 seconds / ADMINISTR. LEVEL / PASSWORD / CALIBR. LEVEL / MAIN INPUT or ANALOG INPUT.

If Calibration level is released

- Press the  and  keys simultaneously / MAIN INPUT or ANALOG INPUT.

If Calibration level is released

- Press the  key for longer than 3 seconds / CALIBR. LEVEL / MAIN INPUT or ANALOG INPUT.

8.2.3 Calibration options

The instrument provides two calibration options for adapting the JUMO dTRANS 02 pH to a pH combination electrode:

One-point offset calibration

The zero point of the pH combination electrode is calibrated, See section 8.3 "Zero point (1-point) calibration", page 48.
Recommended only for special applications, such as ultra-pure water.

Two-point calibration

The zero point and slope of the combination electrode are calibrated, See section 8.4 "2-point calibration", page 49.
This is the recommended calibration for most sensors.

Three-point calibration

In three-point calibration, the zero point and the slope are calibrated in the acidic range and the slope is calibrated in the alkaline range, See section 8.4 "2-point calibration", page 49.
This calibration is recommended with heightened requirements for accuracy.

8 Calibrating a pH measurement chain

8.3 Zero point (1-point) calibration

- * Make preparations, See section 8.2 "General information", page 46 .
- * Start calibration, See section 8.2.2 "Ways to start the calibration", page 47.
- * Select zero point calibration.

ZERO POINT	>
2-POINT	>
3-POINT	>

- * Immerse the combination electrode in a buffer solution with a known pH value.
- * Start the zero point calibration with the  key.



Now the source of temperature acquisition can be selected (manually, or using the temperature input of the basic board, or the temperature input via the optional board). This source will be active for the duration of the calibration.

An example follows: Manual temperature entry:

CALIB	
TEMP. -COMP. SOURCE	
MAN. TEMPERATURE	

- * With manual temperature entry, use the  and  keys to set the calibration solution temperature and confirm your entry with the  key.

E1	CALIB
INPUT	+025.0 °C
TEMP.	

- * Wait until the display value has stabilized; then press  to continue.

CALIB	
MEASUREM.	6.02
REFERENCE	pH
	25.0 °C

- * Set the displayed value to the buffer solution value with the  or  keys;

8 Calibrating a pH measurement chain

then press PGM to continue.

E1 CALIB	
INPUT	+06.10
REFERENCE	pH

* Use the PGM key to accept the zero point or the EXIT key to reject it.

CALIB	
ZERO POINT	7.10pH

The instrument returns to measuring mode.

MEASURING	7.37
25.0°C	pH

8.4 2-point calibration



The buffer solutions (reference solutions) used for calibration must differ by at least 2 pH!

During the calibration, the temperature of the two buffer solutions must be identical and remain constant!

- * Make preparations, See section 8.2 "General information", page 46 .
- * Start calibration, See section 8.2.2 "Ways to start the calibration", page 47.
- * Select 2-point calibration.

ZERO POINT	>
2-POINT	>
3-POINT	>

- * Immerse the combination electrode in the first buffer solution with the known pH value.
- * Start the two-point calibration with the PGM key.

8 Calibrating a pH measurement chain



Now the source of temperature acquisition can be selected (manually, or using the temperature input of the basic board, or the temperature input via the optional board). This source will be active for the duration of the calibration.

An example follows: Manual temperature entry:

CALIB	
TEMP. -COMP. SOURCE	
MAN. TEMPERATURE	

- * With manual temperature entry, use the  and  keys to set the calibration solution temperature and confirm your entry with the  key.

E1	CALIB
INPUT	+025.0 °C
TEMP.	

- * Wait until the display value has stabilized; then press  to continue.

CALIB	
MEASUREM.	7.06
REF. 1	pH
	25.0 °C

- * Set the displayed value to the value of the first buffer solution with the  and  keys; then press  to continue.

CALIB	
INPUT	+07.03
REF. 1	pH

- * Rinse and dry the pH combination electrode.
- * Immerse the pH combination electrode in the second buffer solution.
- * Wait until the display value has stabilized; then press  to continue.

CALIB	
MEASUREM.	4.03
REF. 2	pH
	25.0 °C

- * Set the displayed value to the second buffer solution value with the  or

8 Calibrating a pH measurement chain

 keys; then press  to continue.

CALIB	
INPUT	+04.01
REF. 2	pH

The zero point and slope determined by the instrument are displayed.

- * Use the  key to accept the calibrated values or reject them with the  key.

CALIB	
ZERO POINT	7.03pH
SLOPE	99.4%

The instrument returns to measuring mode.

MEASURING	7.37
25.0°C	pH

8.5 3-point calibration



The buffer solutions (reference solutions) used for calibration must have the following values:

Buffer solution 1: in the neutral range (if possible precisely 7 pH)

Buffer solution 2: Greater than 9 pH

Buffer solution 3: Less than 5 pH

The temperature of the buffer solutions must be equal and remain constant during calibration!

The buffer solutions can be used in any order during the calibration.

- * Make preparations, See section 8.2 "General information", page 46 .
- * Start calibration, See section 8.2.2 "Ways to start the calibration", page 47.
- * Select 3-point calibration.

ZERO POINT	>
2-POINT	>
3-POINT	>

- * Immerse the combination electrode in the first buffer solution with the known pH value.

8 Calibrating a pH measurement chain

- * Start the 3-point calibration with the  key.



Now the source of temperature acquisition can be selected (manually, or using the temperature input of the basic board, or the temperature input via the optional board). This source will be active for the duration of the calibration.

An example follows: Manual temperature entry:

CALIB	
TEMP. -COMP. SOURCE	
MAN. TEMPERATURE	

- * With manual temperature entry, use the  and  keys to set the calibration solution temperature and confirm your entry with the  key.

E1	CALIB
INPUT	+025.0 °C
TEMP.	

- * Wait until the display value has stabilized; then press  to continue.

CALIB	
MEASUREM.	4.01
REF. 1	pH
	25.0 °C

- * Set the displayed value to the value of the first buffer solution with the  and  keys; then press  to continue.

CALIB	
INPUT	+04.02
REF. 1	pH

- * Rinse and dry the combination electrode.
- * Immerse the combination electrode in the second buffer solution with the known pH value. Wait until the display value has stabilized; then press  to continue

CALIB	
MEASUREM.	6.96
REF. 2	pH
	25.0 °C

- * Set the displayed value to the second buffer solution value with the  or

8 Calibrating a pH measurement chain

 keys; then press  to continue.

CALIB	
INPUT	+07.01
REF. 2	pH

- * Rinse and dry the combination electrode.
- * Immerse the combination electrode in the third buffer solution with the known pH value. Wait until the display value has stabilized; then press  to continue.

CALIB	
MEASUREM.	10.01
REF. 3	pH
	25.0 °C

- * Set the displayed value to the third buffer solution value with the  and  keys; then press  to continue.

CALIB	
INPUT	+10.03
REF. 3	pH

The zero point of the combination electrode determined by the instrument and its slope in the acidic and alkaline ranges of the characteristic curve are also displayed.

- * Use the  key to accept the calibrated values or reject them with the  key.

CALIB	
ZERO POINT	7.01 pH
SLOPE ACID	100.3 %
SLOPE ALCA	99.4 %

The instrument returns to measuring mode.

MEASURING	7.37
25.0 °C	pH

8 Calibrating a pH measurement chain

8.6 pH Antimony measurement chain

Antimony measurement chains are calibrated similarly to "normal" pH measurement chains.

- General information on calibration See "General information" page 46.
- Zero point calibration See section 8.3 "Zero point (1-point) calibration", page 48.
- 2-point calibration See section 8.4 "2-point calibration", page 49.
- 3-point calibration See section 8.5 "3-point calibration", page 51.

8.7 ISFET pH combination electrodes

ISFET pH combination electrodes are calibrated similarly to "normal" pH measurement chains.

- General information on calibration See "General information" page 46.
- Zero point calibration See section 8.3 "Zero point (1-point) calibration", page 48.
- 2-point calibration See section 8.4 "2-point calibration", page 49.
- 3-point calibration See section 8.5 "3-point calibration", page 51.

9 Calibrating a redox measurement chain

9.1 Notes



During calibration, relays and analog output signals adopt their configured states!



When is calibration required?

- At regular intervals (depending on the sample medium and requirements).
- If negative values appear in the top display.
- If the top display indicates "Underrange / Overrange".

Every successfully completed calibration is documented in the calibration logbook, See section 12 "Calibration logbook", page 79.

9.2 General information

The electrical properties of all sensors vary slightly from instance to instance and also change during operation (due to deposits or wear, etc.). This changes the output signal of the sensor.

9.2.1 Requirements

- The instrument must be supplied with voltage, See section 4 "Elektrischer Anschluss", page 13 ff.
 - A redox sensor must be connected to the transmitter.
-



For a configuration example See section 7.2.1 "Measuring the pH value with pH combination electrode", page 41.

A redox sensor can be

- connected directly to the main input or
- connected to the "Analog input (universal)" optional board via a 2-wire transmitter.

A temperature compensation is **not** performed during the measurement of the redox potential!

- "REDOX" must be configured as sensor in the basic setting.
- The instrument is in Measurement mode.

9 Calibrating a redox measurement chain

9.2.2 Ways to start the calibration

Select the input to which the pH sensor is connected.



If Calibration level is not released

- Press the  key for longer than 3 seconds / ADMINISTR. LEVEL / PASSWORD / CALIBR. LEVEL / MAIN INPUT or OPTION INPUT.

If Calibration level is released

- Press the  and  keys simultaneously / MAIN INPUT or OPTION INPUT.

If Calibration level is released

- Press the  key for longer than 3 seconds / CALIBR. LEVEL / MAIN INPUT or OPTION INPUT.

9.2.3 Calibration options

The instrument offers two calibrating options for adjusting it to the redox measurement chain.

- One-point calibration
If "mV" was configured as UNIT.
- One-point calibration
If "mV" or "CUST. SPECS." was configured as UNIT.

One-point offset calibration

The zero point of the pH combination electrode is calibrated, See section 8.3 "Zero point (1-point) calibration", page 48.

Recommended only for special applications, such as ultra-pure water.

Two-point calibration

The zero point and slope of the combination electrode are calibrated, See section 8.4 "2-point calibration", page 49.

This is the recommended calibration for most sensors.

9 Calibrating a redox measurement chain

9.3 Zero-point calibration (one-point offset calibration)



Zero point calibration is only available if the unit is configured as "mV"!

- * Make preparations, See section 9.2 "General information", page 55 .
- * Start calibration, See section 9.2.2 "Ways to start the calibration", page 56.
- * Select zero point calibration.

ZERO POINT	>

- * Immerse the combination electrode in a test solution with a known redox potential.
- * Start the zero point calibration with the **PGM** key.

CALIB	
MEASUREM.	414
REFERENCE	mV

Wait until the display value has stabilized; then press **PGM** to continue.

- * Set the displayed value to the test solution value with the **▼** or **▲** keys; then press **PGM** to continue.

CALIB	
INPUT	+0432
REFERENCE	mV


The zero point determined by the instrument is displayed.

CALIB	
ZERO POINT	17.8mV

- * Use the **PGM** key to accept the value or the **EXIT** key to reject it.

9 Calibrating a redox measurement chain

The instrument returns to measuring mode.



Calibration is complete

After rinsing, the combination electrode can again be used to take measurements.

9.4 2-point calibration



This procedure can be used to scale the absolute input signal (mV) to a displayed relative value (%). That greatly simplifies the evaluation of the measured value (good / bad).

Two-point calibration is only available if the unit is configured as "%" or "Cust. specs."!

- * Make preparations, See section 9.2 "General information", page 55 .
- * Start calibration, See section 9.2.2 "Ways to start the calibration", page 56.
- * Select 2-point calibration.



- * Immerse the combination electrode in a solution with a known "good" redox potential.
- * Start the 2-point calibration with the  key. Wait until the display value has stabilized; then press  to continue.



- * Set the displayed value to the relative "good" value (in this example 20%) with the  and  keys; then press  to continue.

9 Calibrating a redox measurement chain

CALIB	
INPUT	+020.0
REF. 1	%

- * Rinse and dry the redox combination electrode.
- * Immerse the combination electrode in a solution with a known "bad" redox potential. Wait until the display value has stabilized; then press PGM to continue.

CALIB	
MEASUREM.	352
REF. 2	mV

- * Set the displayed value to the relative "bad" value (in this example 80%) with the ▼ and ▲ keys; then press PGM to continue.

CALIB	
INPUT	+080.0
REF. 2	%

- * The zero point and slope determined by the instrument are displayed.

CALIB	
ZERO POINT	-39 %
SLOPE	493 %

- * Use the PGM key to accept the calibrated values or reject them with the EXIT key.

MEASURING	80
25.0°C	%

The instrument returns to measuring mode.

Calibration is complete

After rinsing, the combination electrode can again be used to take measurements.

10 Calibrating an ammonia measuring cell

10.1 Notes



During calibration, relays and analog output signals adopt their configured states!



When is calibration required?

- At regular intervals (depending on the sample medium and requirements).
- If negative values appear in the top display.
- If the top display indicates "Underrange / Overrange".

Every successfully completed calibration is documented in the calibration logbook, See section 12 "Calibration logbook", page 79.

10.2 General information

The electrical properties of all sensors vary slightly from instance to instance and also change during operation (due to deposits or wear, etc.). This changes the output signal of the sensor.

The transmitter uses a typical, concentration-dependent characteristic to measure ammonia with "normal" accuracy requirements. The individual properties of the sensor are taken into account here by offsetting the zero point. This considerably reduces the effort required for calibration.

The transmitter software is specially adapted for coolant monitoring.

10.2.1 Requirements

- The instrument must be supplied with voltage, See section 4 "Elektrischer Anschluss", page 13 ff.
 - An ammonia sensor must be connected to the transmitter.
-



For a configuration example See section 7.2.1 "Measuring the pH value with pH combination electrode", page 41.

An ammonia sensor can be

- connected directly to the main input or
 - connected to the "Analog input (universal)" optional board via a 2-wire transmitter.
-

- "AMMONIA" must be configured as sensor in the basic setting.

10 Calibrating an ammonia measuring cell

10.2.2 Ways to start the calibration

Select the input to which the sensor is connected.



If Calibration level is not released

- Press the  key for longer than 3 seconds / ADMINISTR. LEVEL / PASSWORD / CALIBR. LEVEL / OPTIONAL INPUT.

If Calibration level is released


- Press the  and  keys simultaneously / OPTION INPUT.

If Calibration level is released

- Press the  key for longer than 3 seconds / CALIBR. LEVEL / OPTION INPUT.

10.3 Zero point (1-point) calibration

- The transmitter is in "Measuring mode".



- * Immerse the combination electrode in a solution **without ammonia**.
- * Make preparations, See "Requirements" page 60 .
- * Start calibration, See "Ways to start the calibration" page 61.



- * Start the zero point calibration with the  key.



Now the source of temperature acquisition can be selected (manually, or using the temperature input of the basic board, or the temperature input via the optional board). This source will be active for the duration of the calibration.

An example follows: Manual temperature entry:

10 Calibrating an ammonia measuring cell

CALIB	
TEMP. -COMP. SOURCE	
MAN. TEMPERATURE	

- * With manual temperature entry, use the  and  keys to set the solution temperature and confirm your entry with the  key.

E1	CALIB
INPUT	+025.0 °C
TEMP.	

- * Wait until the display value has stabilized; then press  to continue

CALIB	
MEASUREM.	-0.1
REFERENCE	mV
	25.0 °C

- * Wait until the display value has stabilized; then press  to continue.

CALIB	
ZERO POINT	-0.1mV

- * Use the  key to accept the calibration result or the  key to reject it.

MEASURING	0
25.0°C	PPM

The instrument returns to measuring mode.

Calibration is complete

After rinsing, the sensor can again be used to take measurements.

11 Calibrating a sensor with a standard signal

11.1 General information



During calibration, relays and analog output signals adopt their configured states!



Sensors with a standard signal output can only be connected to an "Analog input (universal)" optional board!

The sensors connected to the instrument should be cleaned and the instrument itself calibrated, at regular intervals (subject to the sample medium).

Every successfully completed calibration is documented in the calibration logbook, See section 12 "Calibration logbook", page 79.

11.1.1 Operating modes

The operating mode selection depends on which sensor (transmitter) is connected.

Linear operating mode

For example sensor for free chlorine, redox, pressure, liquid level or humidity

pH operating mode

For example pH sensor

Conductivity operating mode

For example sensor for conductivity, concentration

Customer specs.

For sensors with non-linear characteristics.

Up to xx interpolation points can be defined in an instrument table.

This allows for an excellent approximation of a non-linear characteristic.

Chlorine, pH and temperature-compensated

Combination of chlorine sensor and pH sensor and temperature sensor.

The measured value for chlorine often depends to a great extent on the pH value of the solution.

The chlorine measurement is compensated depending on the pH value in this operating mode. The pH measurement is temperature-compensated

11 Calibrating a sensor with a standard signal

11.1.2 Calibration options

Different calibration options are available depending on the operating mode.

Operating mode	Calibration options					Page
	1-point	2-point	Limit point	Rel. cell const.	Temp. coeff.	
Linear	X	X	X	-	-	65
pH	X	X	-	-	-	69
Conductivity	-	-	-	X	X	70
Concentration	-	-	-	X		76
Customer specs.	Due to the table with interpolation points, no calibration is required					
Chlorine, pH-compensated	-	-	X	-	-	77

- With **one-point (offset) calibration**, the zero point of the sensor is calibrated.
- With **two-point calibration**, the zero point and slope of the sensor are calibrated. This is the recommended calibration for most sensors.
- With **one-point final value calibration**, the slope of the sensor is calibrated. This is the recommended calibration for chlorine sensors, for example.
- **Calibration of relative cell constant**
With conductivity measuring cells only.
- **Calibration of the temperature coefficient**
With conductivity measuring cells only.

11.1.3 Ways to start the calibration

Select the input to which the sensor is connected.

MAIN INPUT	>
OPT. INPUT 3	>

If Calibration level is not released

- Press the  key for longer than 3 seconds / ADMINISTR. LEVEL / PASSWORD / CALIBR. LEVEL / OPTIONAL INPUT.

If Calibration level is released

- Press the  and  keys simultaneously / OPTION INPUT.

If Calibration level is released

- Press the  key for longer than 3 seconds / CALIBR. LEVEL / OPTION INPUT.

11 Calibrating a sensor with a standard signal

11.2 Linear operating mode

11.2.1 1-point calibration



This example is based on a liquid level measurement (as a %).
The input signal is provided by a pressure transmitter.

- The transmitter is in "Measuring mode".

MAIN VAL.	7.00 pH
TEMP. INP.	25.0 °C
OPT. IN 3	2.5 %

- * Now bring the system to a defined state (e.g. when measuring liquid level, empty the container).
- * Start the calibration, See "Ways to start the calibration" page 64.
- * Select the zero point calibration with the PGM key.

ZERO POINT	>
LIMIT POINT	>
2-POINT	>

- * Wait until the display value has stabilized; then press PGM to continue.

CALIB	
MEASUREM.	2.5
REFERENCE	%

Set the displayed value to the required value (usually 0%) with the ▼ and ▲ keys; then press PGM to continue.

CALIB	
INPUT	+000.0
REFERENCE	%

The zero point determined by the instrument is displayed.

11 Calibrating a sensor with a standard signal

CALIB	
ZERO POINT	-2.5%

Use the PGM key to accept the value or the EXIT key to reject it.
The instrument returns to measuring mode.

MAIN VAL.	7.00 pH
TEMP. INP.	25.0 °C
OPT. IN 3	0.0 %

Calibration is complete

After rinsing, the sensor can again be used to take measurements.

11.2.2 Two-point calibration



The values determined during calibration (zero point and slope) work out as follows:

$$\text{Display} = \frac{\text{Input value}}{\text{Slope}} + \text{Zero point}$$

This example is based on a liquid level measurement. The input signal is provided by a pressure transmitter.

- The transmitter is in "Measuring mode".

MAIN VAL.	7.00 pH
TEMP. INP.	25.0 °C
OPT. IN 3	2.5 %

- * Now bring the system to a defined state (e.g. when measuring liquid level, empty the container).
- * Start the calibration, See "Ways to start the calibration" page 64.
- * Select the 2-point calibration with the PGM key.

11 Calibrating a sensor with a standard signal

ZERO POINT	>
LIMIT POINT	>
2-POINT	>

- * Wait until the display value has stabilized; then press  to continue.

CALIB	
MEASUREM.	2.5
REF. 1	%

- * Set the displayed value to the required value (usually 0) with the  and  keys; then press  to continue.

CALIB	
INPUT	+000.0
REF. 1	%

- * Now bring the system to a second defined state (e.g. when measuring liquid level, container full).
Wait until the display value has stabilized; then press  to continue

CALIB	
MEASUREM.	94.9
REF. 2	%

- * Set the displayed value to "Maximum" (usually 100%) with the  and  keys; then press  to continue.

CALIB	
INPUT	+100.0
REF. 2	%

The zero point and slope determined by the instrument are displayed.

CALIB	
ZERO POINT	-2.7%
SLOPE	108.2%

11 Calibrating a sensor with a standard signal

- * Use the **PGM** key to accept the calibrated values or reject them with the **EXIT** key.
- * The instrument returns to measuring mode.

MAIN VAL. 7.00 pH	
TEMP. INP. 25.0 °C	
OPT. IN 3 100.0 %	

Calibration is complete

After rinsing, the sensor can again be used to take measurements.

11.2.3 Calibration end point



This example is based on a measurement of free chlorine. The input signal is provided by a corresponding transmitter.

- The transmitter is in "Measuring mode".

MAIN VAL. 7.00 pH	
TEMP. INP. 25.0 °C	
OPT. IN 3 1.59 PPM	

- * The process must now be brought to the state that is as relevant as possible to the final value (e.g. when measuring chlorine, the required concentration).
- * Start the calibration, See "Ways to start the calibration" page 64.
- * Select the limit point calibration with the **PGM** key.

ZERO POINT	>
LIMIT POINT	>
2-POINT	>

- * Wait until the display value has stabilized; then press **PGM** to continue.

CALIB	
MEASUREM.	1.94
REFERENCE	PPM

Set the displayed value to the measured reference value with the **▼** or **▲** keys; then press **PGM** to continue.

11 Calibrating a sensor with a standard signal

CALIB	
INPUT	+02.00
REFERENCE	PPM

The slope determined by the instrument is displayed.

* Use the key to accept the value or the key to reject it.

CALIB	
SLOPE	97.5%

* The instrument returns to measuring mode.

MAIN VAL.	7.00 pH
TEMP. INP.	25.0 °C
OPT. IN 3	2.00 PPM

Calibration is complete

After rinsing, the sensor can again be used to take measurements.

11.3 pH operating mode

11.3.1 Zero point (1-point) calibration



This example is based on a glass combination electrode with a connected two-wire transmitter.

- The transmitter is in "Measuring mode".

MAIN VAL.	7.00 pH
TEMP. INP.	25.0 °C
OPT. IN 3	6.12 pH

* Perform calibration, See section 8.3 "Zero point (1-point) calibration", page 48.

11 Calibrating a sensor with a standard signal

11.3.2 2-point calibration



This example is based on a glass combination electrode with a connected two-wire transmitter.

- The transmitter is in "Measuring mode".

MAIN VAL. 7.00 pH	
TEMP. INP.	25.0 °C
OPT. IN 3	6.12 pH

- * Perform calibration, See section 8.4 "2-point calibration", page 49.

11.4 Conductivity operating mode

11.4.1 Calibration of the relative cell constant



This example is based on a conductivity cell with a connected two-wire transmitter.

- The transmitter is in "Measuring mode".

MAIN VAL. 7.00 pH	
TEMP. INP.	25.0 °C
OPT. IN 3	109 µS/cm

- * Immerse the conductivity sensor in a reference solution with a known conductivity.
- * Start the calibration, See "Ways to start the calibration" page 64.
- * Select REL. CELL CONST.
- * Press the  key.

TEMP. COEFF. LIN.	>
REL. CELL CONST.	>

- * When the measured value is stable, press the  key

11 Calibrating a sensor with a standard signal

CALIB	
MEASUREM.	1950
REFERENCE	$\mu\text{S}/\text{cm}$

- * The measured conductivity value flashes on the display.

CALIB	
INPUT	+02000
REFERENCE	$\mu\text{S}/\text{cm}$

- * Use the  or  keys to set the value to the actual conductivity.
- * Press the  key;
the relative cell constant determined by the instrument is displayed (as a %).

CALIB	
CELL CONST	102.6 %

- * Use the  key to accept the temperature coefficient or the  key to reject it.

MAIN VAL.		7.00 pH
TEMP. INP.		25.0 °C
OPT. IN 3		2000 $\mu\text{S}/\text{cm}$

The current measurement value and the temperature are displayed.

Calibration is complete

After rinsing, the sensor can again be used to take measurements.

11 Calibrating a sensor with a standard signal

11.4.2 Calibration of the temperature coefficient

Linear temperature coefficient



This example is based on a conductivity cell with a connected two-wire transmitter.

- The transmitter is in "Measuring mode".

MAIN VAL.	7.00 pH
TEMP. INP.	25.0 °C
OPT. IN 3	109 µS/cm

- * Immerse the conductivity sensor in the sample medium.

Start the calibration, See "Ways to start the calibration" page 64.

- * Select "LINEAR TEMP. COEF".

TEMP. COEFF. LIN.	>
REL. CELL CONST.	>

The current sensor temperature flashes in the display (1).

CALIB	
INPUT	024.4 °C
WORK-TEMP.	
< 20.0 °C	> 30.0 °C

 (1)

The working temperature must be at least 5°C above or below the reference temperature (25.0°C).

- * Enter the required working temperature and confirm your entry.
The LC display now shows the selected working temperature (flashing) (2).

CALIB	
INPUT	+075.0 °C
WORK-TEMP.	
< 20.0 °C	> 30.0 °C

 (2)

11 Calibrating a sensor with a standard signal

* Press the  key.

CALIB		
T1	25.0 °C	416
T2	74.4 °C	μS/cm
		24.5 °C

The conductivity (399 μS/cm) at the current temperature (24.3°C) now appears on the right of the LC display.

The temperatures T1 (25°C) and T2 (70.0°C) that have yet to be triggered are shown on the left.

* Press the  key.

* Heat the sample medium until the working temperature is reached.



During calibration, the rate of temperature change in the measurement solution must not exceed 10°C/min.

Calibration is also possible in the cooling process (with a falling temperature). It starts above the working temperature and ends below the working temperature.

As soon as the temperature of the sample medium exceeds T1 (25°C), this is hidden on the display. The uncompensated conductivity at the current temperature is displayed on the right.

CALIB		
		833
T2	75.0 °C	μS/cm
		74.6 °C

If the temperature of the medium exceeded T2 (73.0°C), the instrument determines the temperature coefficient.

The LC display now shows the determined temperature coefficient as %/K.

CALIB	
TEMP. COEFF	1.99 %/K

* Use the  key to accept the temperature coefficient or the  key to reject it.

MAIN VAL.	7.00 pH
TEMP. INP.	75.0 °C
OPT. IN 3	417 μS/cm

11 Calibrating a sensor with a standard signal

The transmitter is in "measuring mode" and displays the compensated conductivity of the solution.

Calibration is complete

After rinsing, the sensor can again be used to take measurements.

With non-linear temperature coefficient (TEMP. COEF. CURVE)



This example is based on a conductivity cell with a connected two-wire transmitter.

The non-linear temperature coefficient can **only** be calibrated with a rising temperature!

The start temperature **must be below** the configured reference temperature (usually 25°C)!

The "TEMP.COEF. CURVE" menu item is only displayed if a temperature sensor is connected and "TEMP.COEF. CURVE" is configured as the type of temperature compensation.

- The transmitter is in "Measuring mode".

MAIN VAL.	7.00 pH
TEMP. INP.	25.0 °C
OPT. IN 3	109 µS/cm

- * Immerse the conductivity sensor in the sample medium.

Start the calibration, See "Ways to start the calibration" page 64.

- * Select "TEMP. COEF. CURVE " and press the  key.

TEMP. COEFF. CURVE	>
REL. CELL CONST.	>

- * Enter the required start temperature (1) for the temp. coef. curve.

CALIB	
INPUT	+024.0 °C
START TEMP	

 (1)

- * Enter the required end temperature (2) for the temp. coef. curve.

CALIB	
INPUT	+075.0 °C
END TEMP	

 (2)

11 Calibrating a sensor with a standard signal

- * Heat the sample medium continuously
 - (3) the current uncompensated conductivity
 - (4) the current temperature of the sample medium
 - (5) the first target temperature

CALIB	
NEXT	416
TEMP.	$\mu\text{S}/\text{cm}$
24.0°C	22.3 °C

(5)

(3)

(4)



During calibration, the rate of temperature change in the measurement solution must not exceed 10°C/min.

During the calibration process, the instrument displays values for the following five temperature interpolation points.

CALIB	
NEXT	426
TEMP.	$\mu\text{S}/\text{cm}$
25.0°C	24.0 °C

The end temperature has been reached

Use the key to accept the temperature coefficients or the key to reject the calibration result.

CALIB	
1: 3.91 %/K	2: 3.67 %/K
3: 3.35 %/K	4: 3.12 %/K
5: 2.87 %/K	6: 2.51 %/K

The LC display now shows the determined temperature coefficients as %/K.

- * Use the key to accept the temperature coefficients or the key to reject the values.

MAIN VAL.	7.00 pH
TEMP. INP.	75.0 °C
OPT. IN 3	417 $\mu\text{S}/\text{cm}$

The transmitter is in "measuring mode" and displays the compensated conductivity of the solution.

Calibration is complete

After rinsing, the sensor can again be used to take measurements.

11 Calibrating a sensor with a standard signal

11.5 Concentration operating mode

11.5.1 Calibration of the relative cell constant



This example is based on a conductivity cell with a connected two-wire transmitter.

The conductivity of a caustic solution is converted into a concentration value [%] by the instrument.

- The transmitter is in "Measuring mode".

MAIN VAL. 7.00 pH	
TEMP. INP.	24.1 °C
OPT. IN 3	2.1 %

- * Immerse the conductivity sensor in a sample medium with a known conductivity.
- * Start the calibration, See "Ways to start the calibration" page 64.
- * Press the  key.

REL. CELL CONST.	>
------------------	---

The measured conductivity value is displayed.

- * Wait until the measurement value has stabilized.
- * Press the  key.

CALIB	
MEASUREM.	104
REFERENCE	mS/cm

- * Use the  and  keys to set the value to the actual conductivity.

CALIB	
INPUT	+00107
REFERENCE	mS/cm

- * Press the  key; the relative cell constant determined by the instrument is displayed (as a %).

CALIB	
CELL CONST	103.3 %

11 Calibrating a sensor with a standard signal

- * Use the  key to accept the relative cell constant or the  key to reject the values.

MAIN VAL. 7.00 pH	
TEMP. INP. 24.2 °C	
OPT. IN 3 2.1 %	

The transmitter is in "measuring mode" and displays the compensated conductivity of the solution.

Calibration is complete

After rinsing, the sensor can again be used to take measurements.

11.6 Chlorine measurement operating mode, pH-compensated

11.6.1 Final value calibration



The pH signal and temperature signal are supplied via the main input, the chlorine signal (standard signal) via the optional input.

- The transmitter is in "Measuring mode".

MAIN VAL. 7.00 pH	
TEMP. INP. 24.2 °C	
OPT. IN 3 1.04 ppm	

Calibrate pH sensor

- * Perform calibration, See section 8 "Calibrating a pH measurement chain", page 46.

Calibrate chlorine sensor

- * The process must now be brought to the state that is as relevant as possible to the final value (e.g. when measuring chlorine, the required concentration).
- * Start the calibration, See "Ways to start the calibration" page 64.
- * Select the limit point calibration with the  key.

11 Calibrating a sensor with a standard signal

LIMIT POINT >

* Wait until the display value has stabilized; then press **PGM** to continue.

CALIB	
MEASUREM.	1.94
REFERENCE	PPM

Set the displayed value to the measured reference value with the **▼** or **▲** keys; then press **PGM** to continue.

CALIB	
INPUT	+02.00
REFERENCE	PPM

The slope determined by the instrument is displayed.

* Use the **PGM** key to accept the value or the **EXIT** key to reject it.

CALIB	
SLOPE	97.5%

The instrument returns to measuring mode.

MAIN VAL.	7.00 pH
TEMP. INP.	25.0 °C
OPT. IN 3	2.00 PPM

Calibration is complete

After rinsing, the sensor can again be used to take measurements.

12.1 General information

The characteristic data for the last 5 successful calibration processed are documented in the calibration logbook.

Calling up

The instrument is in Measurement mode.
* Press the  key for longer than 3 seconds.

```
USER LEVEL >
ADMINISTR.-LEVEL >
CALIBR.-LEVEL >
CALIBR.-LOGBOOK >
```

Select input

Briefly press the  key.

```
MAIN INPUT >
OPT. INPUT 1 >
OPT. INPUT 2 >
OPT. INPUT 3 >
```

Most recent successful calibration



The "time stamp" in the following screen printouts (top left, for example 11-06-06 12:02) only appear if optional slot 3 is fitted with the "Datalogger with interface RS485"!

* Briefly press the  key.

```
00000 HRS.
ZERO POINT 6.95 pH
SLOPE ACID 100.7 %
SLOPE ALCA 101.7 %
```

Next most recent successful calibration


* Briefly press the  key.

```
00000 HRS.
ZERO POINT 7.05 pH
SLOPE 98.4 %
```

12 Calibration logbook

Next most recent successful calibration

* Briefly press the  key.



00000 HRS.
ZERO POINT 7.10 PH

The image shows a rectangular LCD screen with a black border. The screen displays two lines of text in a monospaced font. The first line reads '00000 HRS.' and the second line reads 'ZERO POINT 7.10 PH'. The right side of the screen has a vertical dotted line and a small black bar at the bottom right corner.

13.1 General information




Apart from faulty installation, incorrect settings on the instrument may also affect the proper functioning of the subsequent process or lead to damage. You should therefore always provide safety equipment that is independent of the instrument and it should only be possible for qualified personnel to make settings.

13.2 Controller functions



"Software" control functions are assigned to "Hardware" outputs for this instrument.



- 1 Software controller for "simple" switching functions (e.g. alarm control)
- 2 Software controller for "higher order" switching functions (e.g. PID controller)
- 3 "Switching" hardware output (e.g. relay)
- 3 "Continuous" hardware output (analog output)

13.2.1 Simple switching functions

Up to four switching functions can be set (limit value 1, 2, 3, 4)
ADMINISTR. LEVEL / PARAMETER LEVEL / LIMIT VALUE CONTR. / LIMIT VALUE x.

13.2.2 Higher order switching functions (PID)

Higher order switching functions are configured at the parameter level via the parameters of "Controller 1 or 2".

ADMINISTR. LEVEL / PARAMETER LEVEL / CONTROLLER / CONTROLLER 1(2) / CONFIGURATION / CONTROLLER TYPE / e.g. PULSE LENGTHS


13 Controller

13.2.3 Typical operator level parameters

Binary outputs	Explanation
Signal source	
No signal	No switching function desired
Limit control 1 to 4	"Simple" switching functions
Alarm function (AF1)	
Alarm function (AF2)	
Alarm function (AF7)	
Alarm function (AF8)	
Controller 1(2)	"Higher order" switching functions
Limit value Pulse width Pulse frequency Steady Modulating	

13.3 Software controllers and outputs

Simple controller functions




- 1 Main board
- 2 Optional board
- L Simple controller
- H Higher order controller
- d Digital output
- a Analog output



If "Simple controller functions" have been configured, only the digital outputs can be controlled!

The operator must configure which of the digital outputs will be controlled - the main board or optional board 1, 2 or 3

Higher order controller functions



- 1 Main board
- 2 Optional board
- L Simple controller
- H Higher order controller
- d Digital output
- a Analog output



If "higher order controller functions" have been configured, both the digital outputs and the analog outputs can be controlled.

The operator must configure which of the outputs will be controlled - the main board or optional board 1, 2 or 3.




Additional explanations, See section 18.1 "Glossary", page 100.

13 Controller

13.4 Configuration of higher order controllers

13.4.1 Structure



13.5 Parameter sets



Different process steps may require different controller settings. The instrument offers the option of creating two parameter sets and then switching between them by means of a binary input.

Defining a parameter set

ADMINISTR. LEVEL / PARAMETER LEVEL / CONTROLLER / 1(2) /
PARAMETER SET 1(2)

See "Controllers" page 113.

Configuring parameter set switchover

ADMINISTR. LEVEL / PARAMETER LEVEL / BINARY INPUTS / BINARY INPUT
1(2) / PARAMET. SWITCHOVER

See "Binary inputs" page 112.

13.6 Sample configurations

13.6.1 Simple limit monitoring

Configuration

Limit monitoring

Limit value 1

Signal source:	Main value
Switching function:	Alarm function  (AF8)
Switching point :	6.50 pH
Hysteresis:	0.50 pH

Limit value 2

Signal source:	Main value
Switching function:	Alarm function  (AF7)
Switching point :	8.50 pH
Hysteresis:	0.50 pH

Configuration of binary output, e.g. relay)

Binary outputs

Binary output 1

Signal source:	Limit monitoring 1
At calibration:	Standard operation
Error:	Inactive
HOLD mode:	Frozen
Turn-on delay:	0 seconds
Turn-off delay:	0 seconds
Wiper time:	0 seconds
Manual mode:	No simulation

Binary output 2

Signal source:	Limit monitoring 2
At calibration:	Standard operation
Error:	Inactive
HOLD mode:	Frozen
Turn-on delay:	0 seconds
Turn-off delay:	0 seconds
Wiper time:	0 seconds
Manual mode:	No simulation

13 Controller

13.6.2 Controller with PID behavior and pulse length output

Configuration of software controllers

Controller 1

Configuration

Controller type:	Pulse lengths
Controller actual value:	Main value
Stroke retransmission:	No signal
Additive disturbance:	No signal
Multiplicative disturbance:	No signal
Min./max. contact:	Min. contact
Inactive/active contact:	Active contact
HOLD mode	0 %
HOLD output:	0 %
Error:	0 %
Alarm control:	Off

Parameter set 1

Min. setpoint:	As required
Max. setpoint:	As required
Setpoint:	6.50 pH
Proportional range:	As required
Reset time:	As required
Rate time:	As required
Period time:	As required
Output limit:	As required
Min. turn-on time:	As required
Alarm tolerance:	As required
Alarm delay:	As required

Controller 2

Configuration

Controller type:	Pulse lengths
Controller actual value ¹ :	Main value
Stroke retransmission ¹ :	No signal
Additive disturbance ¹ :	No signal
Multiplicative disturbance ¹ :	No signal
Min./max. contact:	Max. contact
Inactive/active contact:	Active contact

¹ This parameter only appears if "Separate controllers" has been configured in special controller functions.

HOLD mode	0 %
HOLD output:	0 %
Error:	0 %
Alarm control:	Off

Parameter set 1

Min. setpoint:	As required
Max. setpoint:	As required
Setpoint:	8.50 pH
Proportional range:	As required
Reset time:	As required
Rate time:	As required
Period time:	As required
Output limit:	As required
Min. turn-on time:	As required
Alarm tolerance:	As required
Alarm delay:	As required

Configuration of binary output, e.g. relay)

Binary outputs

Binary output 1

Signal source:	Controller 1 output 1
----------------	-----------------------

Binary output 2

Signal source:	Controller 2 output 1
----------------	-----------------------

14 Setup program

14.1 Configurable parameters


Both the setup program (20/00560380) and the PC interface cable with USB/TTL converter (70/00456352) are available as options and provide a convenient way to adapt the transmitter to meet requirements:

- Setting the measuring range.
- Setting the behavior of outputs when the measuring range is exceeded.
- Setting the functions of switching outputs K1 to K8.
- Setting the functions of the binary inputs.
- Setting a customized characteristic
- etc.



Data can only be transferred from or to the transmitter if it is supplied with voltage, See section 5 "Installation", page 15ff.

Connection




- (1) JUMO dTRANS 02 pH
- (2) PC interface cable with USB/TTL converter,
Sales no.:70/00456352
- (3) PC or notebook

14.2 Documenting the instrument configuration

- * Start the setup program
- * Establish the connection to the instrument (1).

Read the instrument configuration (2).




Datei-Info-Kopf:	
Gerätename:	dTRANS02
Geräte-SW-Version:	269.01.xx
VDN:	
Erstellungsdatum:	07.06.2011
Änderungsdatum:	07.06.2011
Programm-Version:	1.00.J
Kurzinfo: Bearbeiter: Typenschlüssel: Auftrag: Zusatzinfo:	
Hardware / Grundeinstellung:	
Hardwaretyp: pH / Redox Regler	
Variante: Standard	
Grundeinstellung Sensor: pH Standard-Elektrode Einheit: pH	
Optionale Bestückung: Optionssteckplatz 1: Analog-Ausgang Optionssteckplatz 2: Analog-Eingang Optionssteckplatz 3: Datenlogger	
Analogeingang Hauptwert:	
pH / Redox:	
Kompensationsquelle:	Temperatur-Eingang
Überwachung Bezugselektrode:	Aus
Überwachung Glaselektrode:	Aus
Filterzeit:	2.0s
Kalibrierintervall:	0 Tage
Differenzmessung:	Aus
Netzfrequenz:	50 Hz
Analogeingang Temperatur:	
Sensortyp: Kein Sensor	
Filterzeit:	2.0s
Manuelle Temperaturvorgabe:	25.0 °C
Offset:	0.0 °C
Analogeingang Optionskarten:	
Analogeingang 2	
Betriebsart:	Linear
Konstant:	XX/xx
Einheit:	µS/cm
Skalierung Anfang:	0.00 µS/cm
Skalierung Ende:	99.99 µS/cm
Signalart:	0 ... 20 mA
Filterzeit:	2.0s
Bearbeiter: dTRANS02 Geräte-SW-Version: 269.01.xx Programm-SW-Version: 1.00.J	
Dokument: Setup2 - geändert - Erstellungsdatum: 07.06.2011 Änderungsdatum: 07.06.2011 Seitenanzahl: 12	



14 Setup program

14.3 Special features for "Datalogger"


- * Start the setup program
- * Establish the connection to the instrument (1).
- * Read the instrument configuration (2).




- * Read data from datalogger (for example table view)
 - Mark datalogger icon (3)
 - Read values from the instrument (4)



14 Setup program



* Export data (for processing in an external program).



Geräteerkennung: yyyyyyyyyyyyyyyyyy													
	Datum	Zeit	Analogwert 1	Einheit 1	Analogwert 2	Einheit 2	Analogwert 3	Einheit 3	Analogwert 4	Einheit 4	Binärausgang 1	Binärausgang 2	Binärausgang 3
1	07.06.2011	14:32:01	7.021104	pH	25	°C	0	%	0	%	0	0	0
2	07.06.2011	14:31:01	7.020878	pH	25	°C	0	%	0	%	0	0	0
3	07.06.2011	14:30:01	7.021447	pH	25	°C	0	%	0	%	0	0	0
4	07.06.2011	14:29:01	7.020861	pH	25	°C	0	%	0	%	0	0	0
5	07.06.2011	14:28:01	7.020949	pH	25	°C	0	%	0	%	0	0	0
6	07.06.2011	14:27:01	7.020753	pH	25	°C	0	%	0	%	0	0	0
7	07.06.2011	14:26:01	7.020559	pH	25	°C	0	%	0	%	0	0	0
8	07.06.2011	14:25:01	7.020248	pH	25	°C	0	%	0	%	0	0	0
9	07.06.2011	14:24:01	7.020679	pH	25	°C	0	%	0	%	0	0	0
10	07.06.2011	14:23:01	7.020659	pH	25	°C	0	%	0	%	0	0	0
11	07.06.2011	14:22:01	7.020184	pH	25	°C	0	%	0	%	0	0	0
12	07.06.2011	14:21:01	7.020	Datenlogger Speichern					0	%	0	0	0
13	07.06.2011	14:20:01	7.020						0	%	0	0	0
14	07.06.2011	14:19:01	7.020						0	%	0	0	0
15	07.06.2011	14:18:01	7.020						0	%	0	0	0
16	07.06.2011	14:17:01	7.019						0	%	0	0	0
17	07.06.2011	14:16:01	7.020						0	%	0	0	0
18	07.06.2011	14:15:01	7.020						0	%	0	0	0
19	07.06.2011	14:14:01	7.020						0	%	0	0	0
20	07.06.2011	14:13:01	7.020						0	%	0	0	0
21	07.06.2011	14:12:01	7.019						0	%	0	0	0
22	07.06.2011	14:11:01	7.019						0	%	0	0	0
23	07.06.2011	14:10:01	7.019						0	%	0	0	0
24	07.06.2011	14:09:01	7.021						0	%	0	0	0
25	07.06.2011	14:08:01	7.020	pH	25	°C	0	%	0	%	0	0	0
26	07.06.2011	14:07:01	7.020673	pH	25	°C	0	%	0	%	0	0	0

15 Eliminating errors and faults

Problem	Possible cause	Action
No measurement display or current output	There is no supply voltage	Check the power supply
Measurement display 0000 or current output 4 mA	Sensor not immersed in medium; level in container too low	Top up the container
	Flow-through fitting is blocked	Clean the flow-through fitting
	Sensor faulty	Replace the sensor
Incorrect or fluctuating measurement display	Sensor faulty	Replace the sensor
	Sensor positioning incorrect	Choose another installation location
	Air bubbles	Optimize assembly
HAUPTWERTEINGANG: OVERRANGE	Measurement overrange	Choose a suitable measuring range
HAUPTWERTEINGANG: UNDERRANGE	Measurement underrange	
ALARM MESSUNG 8888 25.7°C pH	Main input: Measurement range "out of range"	
HAUPTINGANG: KOMPENSAT. -BEREICH	Compensation range has been left	
TEMPERATUREINGANG: OVERRANGE	Measurement overrange	Choose a suitable measuring range
TEMPERATUREINGANG: UNDERRANGE	Measurement underrange	
ALARM MESSUNG 8888 8888 °C pH	Temperature input: Measurement range "out of range"	
OPTIONSEINGANG 1: KOMPENSAT. -BEREICH	Compensation range has been left	Choose a suitable measuring range
OPTIONSEINGANG 1: OUT OF RANGE	Temperature input: Measurement range "out of range"	
GLASELEK. -IMPEDANZ ZU HOCH	Coating	Clean (glass) electrode. Replace (glass) electrode.

15 Eliminating errors and faults

GLASELEK. -IMPEDANZ ZU NIEDRIG	Membrane glass damaged	Replace (glass) electrode.
BEZUGSEL. -IMPEDANZ ZU HOCH	Coating	Clean reference electrode. Replace reference electrode.
ABHÄNGIGE PARAMETER WURDEN ANGEPASST	Configuration change	OK
DATENLOGGER WIRD GELÖSCHT ...	Configuration change	OK
EBENE GESPERRT	Inhibit via binary contact	Check configuration and unlock if necessary
PARAMETER GESPERRT	Do not release	If appropriate release in the release level
PASSWORT FALSCH		Test
TASTATUR VERRIEGELT	Inhibit via binary contact	Check configuration and unlock if necessary
KONFIGURATION WURDE WIEDER HERGESTELLT	Cancel in basic setting	OK
PROFIBUS FEHLER		Check hardware
UNZULÄSSIGE HARDWARE-BESTÜCKUNG		Check fitting, adjust if necessary
FEHLER ECHTZEITUHR: UHRZEIT NEU STELLEN	Instrument had no power supply for a very long time	Establish power supply Set the datalogger time

16 Technical data

Inputs (main board)

Main input	Measuring range/control range	Accuracy	Effect of temperature
pH value	-2 - 16 pH	≤ 0.3% of range	0.2%/10°C
Redox potential	-1500 - 1500 mV	≤ 0.3% of range	0.2%/10°C
NH ₃ (ammonia)	0 - 9999 ppm	≤ 0.3% of range	0.2%/10°C
Secondary input			
Temperature Pt100/1000	-50 to 250°C ¹	≤ 0.25% of range	0.2%/10°C
Temperature NTC/PTC	0.1 - 30 kΩ Entry via table with 20 value pairs	≤ 1.5% of range	0.2%/10°C
Standard signal	0(4) - 20 mA or 0 - 10 V	0.25% of range	0.2%/10°C
Resistance transmitter	Minimum: 100 Ω Maximum: 3 kΩ	+/- 5 Ω	0.1%/10°C

¹ Selectable in °F.

Resistance thermometer inputs (optional board)

Designation	Connection type	Measuring range	Measuring accuracy		Effect of ambient temperature
			3-wire/4-wire	2-wire	
Pt100 DIN EN 60751 (factory-set)	2-wire/3-wire 4-wire	-200 - +850°C	≤ 0.05%	≤ 0.4%	50 ppm/°C
Pt1000 DIN EN 60751 (factory-set)	2-wire/3-wire 4-wire	-200 - +850°C	≤ 0.1%	≤ 0.2%	50 ppm/°C
Sensor lead resistance	Maximum 30 Ω per line with three- and four-wire circuit				
Measurement current	approx. 250 µA				
Lead compensation	Not required for three- and four-wire circuit. With a 2-wire circuit, lead resistance can be compensated in the software by correcting the process value.				

Standard signals inputs (optional board)

Designation	Measuring range	Measuring accuracy	Ambient temperature effect
Voltage	0(2) - 10 V	≤ 0.05%	100 ppm/°C
Electrical current	0 - 1 V Input resistance R _E > 100 kΩ	≤ 0.05%	100 ppm/°C
Resistance transmitter	Minimum: 100 Ω Maximum: 4 kΩ	+/- 4 Ω	100 ppm/K

Temperature compensation

Measurement variable	Compensation	Range ¹
pH value	Yes	-10 - 150°C
Redox potential	No	Not applicable
NH ₃ (ammonia)	Yes	-20 - +50°C

¹ Note the sensor operating temperature range!

Measuring circuit monitoring

Inputs	Overrange/underrange	Short circuit	Broken lead
pH value	Yes	Yes ¹	Yes ¹
Redox potential	Yes	No	No
NH ₃ (ammonia)	Yes	No	No
Temperature	Yes	Yes	yes
Voltage 2 - 10 V 2 - 10 V	Yes	Yes	Yes
	Yes	No	No
Current 4 - 20 mA 0 - 20 mA	Yes	Yes	Yes
	Yes	No	No
Resistance transmitter	No	No	Yes

16 Technical data

¹ The sensor can be monitored for short circuit and broken lead during the pH measurement by activating the impedance measurement.

Impedance measurement

The impedance measurement can optionally be activated.

Because it depends on some boundary parameters, note the following points:

- Only glass-based sensors are permitted.
- The sensors must be connected directly to the transmitter.
Only one impedance converter may be used in the measuring circuit!
- The maximum permissible line length between sensor and transmitter is 10 m.
- Liquid resistances are included directly in the measurement results.

We therefore recommend activating the measurement in liquids beginning with a minimum conductivity of about 100 $\mu\text{S/cm}$.

Binary input

Activation	Floating contact is open: function is not active Floating contact is closed: function is active
Function	Key lock, manual mode, HOLD, HOLD inverse, alarm suppression, freeze measured value, level lock, reset partial quantity, reset total quantity, parameter set changeover

Controller

Controller type	Limit comparators, limit controllers, pulse length controllers, pulse frequency controllers, modulating controllers, continuous controllers
Controller structure	P / PI / PD / PID

Outputs

Relay (changeover) - Contact rating - Contact service life	Basic board	5 A at 240 VAC resistive load 350,000 operations at nominal load/750,000 operations at 1 A
Supply voltage for 2-wire transmitter	Basic board	Electrically isolated, non-controlled DC 15.8 - 15.2V; 30 . 50 mA
Power supply for ISFET	Optional board	DC +/- 5 V; 5 mA
Power supply for inductive proximity switch	Optional board	DC 12 V; 10 mA
Relay (changeover) - Contact rating - Contact service life	Optional board	8 A at AC 240 V resistive load 100,000 operations at nominal load/350,000 operations at 3A
Relay SPST (normally open) - Contact rating - Contact service life	Optional board	3A at 240VAC resistive load 350,000 operations at nominal load/900,000 operations at 1 A
Semiconductor relay - Contact rating - Protective circuit	Optional board	1 A at 240 V Varistor
Semiconductor switch (photo MOS)	Optional board	$U \leq 50 \text{ V AC/DC}$ $I \leq 200 \text{ mA}$
Voltage - Output signals - Load resistance - Accuracy	Optional board	0 - 10 V / 2 - 10 V $R_{\text{load}} \geq 500 \Omega$ $\leq 0.5\%$
Electrical current - Output signals - Load resistance - Accuracy	Optional board	0 - 20 mA / 4 - 20 mA $R_{\text{load}} \leq 500 \Omega$ $\leq 0.5\%$

Display

Type	LC graphic display, blue with background lighting, 122 x 32 pixels
------	--

16 Technical data

Electrical data

Supply voltage (switch-mode PSU)	AC 110 - 240 V -15/+10%; 48 - 63 Hz or AC/DC 20-30 V; 48 - 63 Hz
Electrical safety	to DIN EN 61010, Part 1 overvoltage category II, pollution degree 2
Power consumption	Max. 13 VA
Data backup	EEPROM
Electrical connection	On the back via screw terminals, conductor cross-section up to max. 2.5 mm ²
Electromagnetic Compatibility (EMC) - Interference emission - Immunity to interference	DIN EN 61326-1 Class A to industrial requirements

Enclosure

Enclosure type	Plastic enclosure for panel mounting to DIN IEC 61554
Depth behind panel	90 mm
Ambient temperature Storage temperature	-5 - +55°C -30 - +70°C
Climatic rating	Rel. humidity ≤90% annual mean, no condensation
Operating position	Horizontal
Enclosure protection	to DIN EN 60529, front IP65, rear IP20
Weight (fully fitted)	about 380 g

Interface

Modbus	
Interface type	RS422/RS485
Protocol	Modbus, Modbus Integer
Baud rate	9600, 19200, 38400
Device address	0 - 255
Max. number of nodes	32
PROFIBUS-DP	
Device address	0 - 255

Approvals/marks of conformity

Mark of conformity	Testing laboratory	Certificates/certification numbers	Test basis	valid for
c UL us	Underwriters Laboratories	Registered	UL 61010-1 CAN/CSA-C22.2 No. 61010-1	JUMO dTRANS pH 02

17 Retrofitting optional boards



Caution:

The instrument **must** be de-energized on the input and output sides!
Optional boards must only be retrofitted by qualified specialists.








ESD:







Optional boards can be damaged by electrostatic discharge. You must therefore prevent electrostatic charges from accumulating during installation and removal. Optional boards should be retrofitted at a grounded workstation.

17.1 Identifying an optional board

The packaging of the optional board is identified by a sales number.


Optional board	Code	Sales No.	Board view
Analog input (universal)	1	70/00442785	
Relay (1 x changeover)	2	70/00442786	
Relay (2 x NO) This board must only be inserted in optional slot 1 or 3!	3	70/00442787	
Analog output	4	70/00442788	
Semiconductor relay 1 A	5		

17 Retrofitting optional boards

Optional board	Code	Sales No.	Board view
MosFET semiconductor switch	6	70/00442790	 A schematic diagram of a rectangular printed circuit board. It features several integrated circuits, resistors, and a large component on the right side. There are also some circular components and a small rectangular component near the bottom center.
Supply voltage output +/- 5 V DC (e.g. for ISFET)	7	70/00442782	 A schematic diagram of a rectangular printed circuit board. It shows a few integrated circuits, resistors, and a large component on the right side. There are also some circular components and a small rectangular component near the bottom center.
Supply voltage output 12 V DC (e.g. for inductive proximity switch)	8	70/00442791	 A schematic diagram of a rectangular printed circuit board. It is densely populated with various electronic components, including many integrated circuits, resistors, and capacitors. There are also some circular components and a small rectangular component near the bottom center.
Interface - RS422/485	10		 A schematic diagram of a rectangular printed circuit board. It features a large central component, possibly a microcontroller or a specialized interface chip, surrounded by various other components like resistors, capacitors, and smaller integrated circuits. There are also some circular components and a small rectangular component near the bottom center.
Datalogger with interface RS422/485	11		 A schematic diagram of a rectangular printed circuit board. It shows a complex arrangement of components, including a large central component, several integrated circuits, resistors, and capacitors. There are also some circular components and a small rectangular component near the bottom center.
Profibus-DP interface	12		 A schematic diagram of a rectangular printed circuit board. It features a few integrated circuits, resistors, and a large component on the right side. There are also some circular components and a small rectangular component near the bottom center.

17 Retrofitting optional boards

17.2 Removing a plug-in module




- (1) Squeeze the front panel together by the left and right sides and remove the plug-in module.

17.3 Inserting a plug-in module



Caution:

No "3" relays (2 x SPST/normally open) may be inserted in slot 2!




- (1) Slot 1 for optional board
 - (2) Slot 2 for optional board
 - (3) Slot 3 for optional board
- (1) Push the optional board into the slot until it locks in place.
 - (2) Push the device plug-in into the enclosure until it locks in place.

18 Appendix


18.1 Glossary

Zero point (1-point) calibration




- With one-point offset calibration, the zero point of the pH combination electrode is calculated, See section 8.3 "Zero point (1-point) calibration", page 48.
Recommended only for special applications, such as ultra-pure water.

2-point calibration



- With two-point calibration, the zero point and slope of the combination electrode are calibrated, See section 8.4 "2-point calibration", page 49.
This is the recommended calibration for most sensors.

3-point calibration




In three-point calibration, the zero point and the slope are calibrated in the acidic range and the slope is calibrated in the alkaline range, See section 8.5 "3-point calibration", page 51.
This calibration is recommended with heightened requirements for accuracy.

Limit value (alarm) function of the binary outputs


	AF1	
	AF2	
	AF7	

18 Appendix



Display of measured values STANDARD



The measurement value, measurement variable and temperature of the measuring material are shown in standard display.



- (1) Operating mode
- (2) Display bottom (temperature input)
- (3) Display top (analog input measurement value)

Display of measured values TENDENCY

The operator can quickly see the direction in which the measurement is changing.



Rising			Steady	Falling		
Greatly	Moderately	Slightly		Slightly	Moderately	Greatly



The measurement tendency (trend) is calculated over the last 10 measurement values.
So with a sampling interval of 500 ms, the last 5 seconds are considered.

Display of measured values BARGRAPH

- Values of the main inputs, input options or math channels (signal source) can be represented as a variable bar (a bar graph).



Scaling the bar

- * Activate "BARGRAPH" as the display of measured values.
- * Select "SCALE START" with .
- * Confirm the selection with .
- * Use and to enter the lower limit of the range to be displayed.
- * Confirm the selection with .
- * Select "SCALE END" with .
- * Use or to enter the upper limit of the range to be displayed.
- * Confirm the selection with .




To return to measuring mode:

Press the key repeatedly or wait for a "timeout".

Measurement display type TREND CHART

Values of the main inputs, input options or math channels (signal source) can be represented as a graph.

The current values appear to the right on the screen.



Scaling the display

- * Activate "TREND CHART" as the display of measured values.
- * Select "SCALE START" with .
- * Confirm the selection with .
- * Use and to enter the lower limit of the range to be displayed.

18 Appendix

- * Confirm the selection with .
- * Select "SCALE END" with .
- * Use  or  to enter the upper limit of the range to be displayed.
- * Confirm the selection with .



To return to measuring mode:
Press the  key repeatedly or wait for a "timeout".

Display of measured values LARGE DISPLAY


Values of the main inputs, input options or math channels (signal source) can be displayed in large format.



Display of measured values 3 MEAS. VALUES


Three values of the main inputs, input options or math channels (signal source) can be displayed simultaneously.

The position of the value to be displayed can be set to "Top", "Center" or "Bottom".




11:43:59	
HAUPTWERT	6.02 pH
OPT. IN 2	5.00 pH
TEMP. EIN.	25.0 °C

Pulse length controller (output active with $x > w$ and P control structure)



If actual value x exceeds setpoint W , the P controller will control in proportion to the control deviation. When the proportional range is exceeded, the controller operates with an output level of 100% (100% clock ratio).

Pulse frequency controller (output active with $x > w$ and P control structure)



If actual value x exceeds setpoint W , the P controller will control in proportion to the control deviation. When the proportional range is exceeded, the controller operates with an output level of 100% (maximum switching frequency).

Calibration timer

The calibration timer indicates (on request) a required routine calibration. The calibration timer is activated by entering the number of days that must expire before there is a scheduled re-calibration (specified by the system or the operator).


18 Appendix

Customer specs. table

In this mode, the input value can be displayed based on a table (max. 20 value pairs). This function is used to display and linearize non-linear input variables. Values can only be entered in the table using the optional setup program.

Cust. specs. characteristic

In this mode, the instrument can model a monotonically increasing input variable to any output value.



The optional setup program is used to enter the requisite value table.

A window titled "Kundenspezifische Kennlinie" with a table for input-output pairs and a text area for instructions. The table has columns "Eingang" and "Ausgang". The text area contains instructions in German about the table's capacity and value ranges.

	Eingang	Ausgang
4	30	30
5	40	50
6	50	80
7	60	85
8	70	90
9	80	93
10	90	98
11	100	100
12		
13		
14		
15		
16		
17		

Hinweis
Bei der kundenspezifischen Tabelle können Sie maximal 20 Stützstellen in die Tabelle eintragen.
Wertebereich Eingangsgröße: 0.00 ... 100.00 %
Wertebereich Ausgangsgröße: -999.900 ... 999.900 gew. %
Bitte beachten Sie, daß die Eingangsgrößen in ihrem Wert ansteigen müssen.

OK Abbrechen

Min./max. value memory

This storage records the minimum and maximum input quantities that have occurred. This information can be used, for example, to assess whether the design of the connected sensor is suitable for the values that actually occur.

The max./min. value memory can be reset,
See section 6.7.6 "Delete min/max values", page 35:

Temperature compensation

The pH value of a measurement solution depends on the temperature. Since the pH value is not always measured at the reference temperature, the instrument is able to perform a temperature compensation.

The sensor signal for the ammonia measurement is temperature-dependent. The instrument can perform temperature compensation.



The redox potential of a measurement solution is **not** temperature-dependent! Temperature compensation is not required.

Special controller functions: Separate controllers

This function is normally deactivated (factory setting or select "No").

In the deactivated state, the software prevents the two controller outputs from being able to work "against each other". So, for example, it is not possible to dose acid and lye at the same time.

If the controllers are separate ("Yes" selection), each controller can be freely configured.

Switch-off of the I-component

This function is normally deactivated (factory setting or select "No").

In the deactivated state, the controller works in accordance with general controller theory.

When I-component switch-off is activated ("Yes" selection), the part of the output level that can be traced back to the I-component is set to zero when the setpoint is reached.

This can be useful with mutual neutralization (acid and lye dosing both possible) in one treatment tank.

Datalogger

Recording duration = about 10 hours with a storage interval of 1 second

Recording duration = about 150 days with a storage interval of 300 seconds

Asymmetrical connection of pH electrodes


Typically pH electrodes are connected asymmetrically to the transmitter. The connection corresponds exactly to the structure of a pH electrode in terms of impedance.

For the asymmetrical connection, the glass electrode is connected to the electronics with a high impedance and the reference electrode is connected with a low impedance. Most transmitters are designed for this connection type.

For both asymmetrical and symmetrical connections, the input impedance of


18 Appendix

the transmitter is about 1000 times greater than the impedance of the connected glass electrode. The impedance of a glass electrode may be as much as 1000 MOhm.



Symmetrical connection of pH electrodes

The symmetrically high-impedance input is an alternative way to connect pH electrodes to the transmitter. In this case both the glass and the reference electrode are connected to the transmitter with high impedance. With this type of connection, it is essential to connect the liquid junction potential to the transmitter as well.



Even difficult electrical environmental conditions can be compensated for with the symmetrical connection.

For example, if a poorly insulated electric stirrer motor is directing a residual current into the sample, this will result in a shift in the potential relative to systems ground.

With the normal asymmetrical connection, a residual current can then flow through the coupling capacitances (which are present in all instruments) to systems ground, thereby causing a measurement error.

With a symmetrical connection, both inputs are directed via operation amplifiers to the instrument electronics. These operation amplifiers block the residual current (to a certain degree) and a measuring error is prevented.

Impedance monitoring

Impedance monitoring of glass pH combination electrodes places high demands on the transmitter electronics. The measurement required for this purpose takes place at the same time the main measured value is recorded. To minimize the electrode load, a response time of up to one minute is possible. With an asymmetrical connection of glass and reference electrode, the overall impedance can be monitored.

Monitoring of the reference electrode is not recommended, since the measured value is difficult to interpret.

The impedance measurement depends on the cable material, the line length and the components used. JUMO special lines for pH measurements are limited in length to 10 m.

If ISFET sensors or impedance converters are used, impedance monitoring is not possible.

Wash timer

The wash timer can be used to implement automated sensor cleaning. To do this, the function is assigned to a switching output.

The cycle time (cleaning interval) can be adjusted in the range from 0.0 to 240.0 hours.

A cycle time of "0.0" means the wash timer is deactivated.

The wash time (cleaning duration) is adjustable from 1 to 1800 seconds.

During the wash time the controller goes into the HOLD state, which is maintained for 10 seconds after completion of the wash time. A sensor calibration within the cycle time restarts the wash timer.

18 Appendix

18.2 Parameters of the User level

When there are numerous instrument parameters to configure, it is advisable to make a note in the table below of all the parameters to be changed and to work through these parameters in the given order.



The following list shows the maximum number of parameters that can be modified.

Some of these parameters will not be visible (and therefore not editable) for your particular instrument, depending on the configuration.

Parameter	Selection / value range Factory setting	New setting
Input pH/redox		
Zero point	5.00 - 7.00 - 9.00 or -9999.99 - 0.00 - +9999.99 mV	
Slope - acidic	xx.xx - xx.xx - xx.xx %	
Slope - alkaline	xx.xx - xx.xx - xx.xx %	
Temperature compensation source	Temperature input Option input 1 Option input 2 Option input 3 Manual temperature input	
Monitoring of the reference electrode	Off On	
Glass electrode monitoring	Off On	
Filter time constant	0.0 - 2.0 - 25.0 seconds	
Calibration interval	0 - 99 days (0 = timer not active)	
Differential measurement	Off Main input - (minus) Option input 1 Main input - (minus) Option input 2 Main input - (minus) Option input 3 Option input 1 - (minus) Main input Option input 2 - (minus) Main input Option input 3 - (minus) Main input	
Supply frequency	50 Hz 60 Hz	
Temperature input		
Temperature sensor	No sensor Pt 100 Pt 1000 Cust. specs. 0 - 20 mA 4 - 20 mA 0 - 10 V 2 - 10 V Resistance transmitter	

Parameter	Selection / value range Factory setting	New setting
Unit	°C/°F % Without unit Cust. specs.	
Scaling start	-100.0 - 0.0 - 499.9°C	
Scaling end	-99.9 - 100.0 - 500.0°C	
Filter time constant	0.0 - 2.0 - 25.0 seconds	
Manual temperature	-99.9 - 25.0 - +99.9°C	
Offset	-99.9 - 0.0 - +99.9°C	
Input options		
Analog inputs 1 to 3		
Operating mode	Off Linear Temperature pH measurement Conductivity Concentration Cust. specs. Stroke feedback Chlorine, pH-compensated	
Signal type	0 - 20 mA 4 - 20 mA 0 - 10 V 2 - 10 V 0 - 1 V Pt100 Pt1000 Cust. specs.	
Connection type	2-wire 3-wire 4-wire	
Display format	XXXX XXX.x XX.xx X.xxx	
Unit	µS/cm mS/cm kΩ*cm MΩ*cm None Cust. specs. mV pH % ppm mg/l	
Scaling start	-9999 - +9998	
Scaling end	-9998 ... +9999	

18 Appendix

Parameter	Selection / value range Factory setting	New setting
Temperature compensation source	Temperature input Option input 1 Option input 2 Option input 3 Manual temperature	
pH compensation source	Main input Option input 1 Option input 2 Option input 3	
Temperature compensation	None Linear TC graph Natural waters ASTM D1125 neutral ASTM D1125 acidic ASTM D1125 alkaline NaOH 0 - 12% NaOH 25 - 50% HNO ₃ 0 - 25% HNO ₃ 36 - 82% H ₂ SO ₄ 0 - 28% H ₂ SO ₄ 36 - 85% H ₂ SO ₄ 92 - 99% HCl 0 - 18% HCl 22 - 44%	
Reference temperature	15.0 - 25.0 - 30.0°C	
Filter time constant	0.0 - 2.0 - 25.0 seconds	
Relative cell constant	20.0 - 100.0 - 500.0 1/cm	
Temperature coefficient	0.00 - 2.20 - 8.00 1/cm	
Zero point	-9999 - 0 - +9999	
Slope	-999.9 - 100.0 - +999.9%	
Binary inputs		
Binary input 1 or 2		
Function	No function Manual mode Hold mode Hold mode inverse Alarm stop Freeze measured value Key lock Lock levels Flow rate measurement Reset day counter Reset total counter Parameter set switchover	

Parameter	Selection / value range Factory setting	New setting
Controllers		
Controller 1 or 2		
Parameter set 1 or 2		
Min. setpoint	-2.00 - 0.00 - 16.00 pH	
Max. setpoint	-2.00 - 16.00 - 16.00 pH	
Setpoint	-2.00 - 0.00 - 16.00 pH	
Setpoint 2	-2.00 - 0.00 - 16.00 pH	
Proportional range	0.00 - 99.99 pH	
Reset time	0.00 - 9999 s	
Derivative time	0.00 - 9999 s	
Period time	2.00 - 60.0 - 999.9 s	
Hysteresis	0.00 - 1.00 - 9.00 pH	
On-delay	0.00 - 999.5 s	
Delayed release	0.00 - 999.5 pH	
Output limit	0 - 100%	
Min. turn-on time	0.20 - 0.50 - 99.50 s	
Actuator time	10 - 60 - 3000 s	
Max. pulse frequency	1 - 60 - 80 1/s	
Alarm tolerance	0.00 - 1.00 - 9.00 pH	
Alarm delay	0.00 - 9999 s	
Configuration		
Controller type	Off Limit value Pulse lengths Pulse frequency Continuous Modulating	
Controller actual value	Main value Not comp. Main value Temperature Option input 1 Option input 1 not compensated Option input 2 Option input 2 not compensated Option input 3 Option input 3 not compensated Math 1 Math 2 Differential signal	

18 Appendix

Parameter	Selection / value range Factory setting	New setting
Stroke retransmission	No signal Main value Not comp. Main value Temperature Option input 1 Option input 1 not compensated Option input 2 Option input 2 not compensated Option input 3 Option input 3 not compensated Math 1 Math 2	
Additive disturbance	No signal Main value Not comp. Main value Temperature Option input 1 Option input 1 not compensated Option input 2 Option input 2 not compensated Option input 3 Option input 3 not compensated Math 1 Math 2	
Multiplicative disturbance	No signal Main value Not comp. Main value Temperature Option input 1 Option input 1 not compensated Option input 2 Option input 2 not compensated Option input 3 Option input 3 not compensated Math 1 Math 2	
Min/max contact	Min contact Max contact	
Make/break contact	Make contact Break contact	
Hold mode	0% 100% Frozen Hold output	
Hold reg. ratio	0 - 100%	
Error	0% 100% Frozen Hold output	

Parameter	Selection / value range Factory setting	New setting
Alarm control	Off On	
Controller special functions		
I-switch-off	Inactive (the controller is working normally) Active (special behavior)	
Separate controllers	No Yes	
Manual mode	Locked Coding Switching	
Limit value control		
Limit values 1 to 4		
Signal source	No signal Main value Not comp. Main value Temperature Option input 1 Option input 1 not compensated Option input 2 Option input 2 not compensated Option input 3 Option input 3 not compensated Math 1 Math 2 Differential signal Flow rate Partial quantity Total quantity Output controller 1 Output controller 2 Setpoint 1 controller 1 Setpoint 2 controller 1 Setpoint 1 controller 2 Setpoint 2 controller 2	
Switching function	Alarm function  (AF1) Alarm function  (AF2) Alarm function  (AF7) Alarm function  (AF8)	
Switching point	2.00 - 0.00 - 16.00 pH	
Hysteresis	0.00 - 9.00 pH	

18 Appendix

Parameter	Selection / value range Factory setting	New setting
Binary outputs		
Binary outputs 1 to 8		
Signal source	No signal Limit value control 1 Limit value control 2 Limit value control 3 Limit value control 4 Controller 1 output 1 Controller 1 output 2 Controller 2 output 1 Controller 2 output 2 Controller alarm 1 Controller alarm 2 Controller alarm Sensor warnings Sensor error Warnings and errors Calibration timer Wash timer Logic 1 Logic 2 Autorange	
At calibration	Standard operation Inactive Active Frozen	
Error	Inactive Active Frozen	
Hold mode	Inactive Active Frozen Standard operation	
Switch-on delay	0.0 - 3600 s	
Switch-off delay	0.0 - 3600 s	
Pulse time ¹	0.0 - 3600 s	
Manual mode	No simulation Inactive Active	

¹ Delayed release is automatically deactivated when wiper times are greater than 0 seconds.

Parameter	Selection / value range Factory setting	New setting
Analog outputs		
Analog outputs 1 to 3		
Signal source	No signal Main value Not comp. Main value Temperature Option input 1 Option input 1 not compensated Option input 2 Option input 2 not compensated Option input 3 Option input 3 not compensated Math 1 Math 2 Differential signal Flow rate Partial quantity Total quantity Output controller 1 Output controller 2 Setpoint 1 controller 1 Setpoint 2 controller 1 Setpoint 1 controller 2 Setpoint 2 controller 2	
Signal type	0 - 20 mA 4 - 20 mA 20 - 0 mA 20 - 4 mA 0 - 10 V 10 - 0 V	
Scaling start	2.00 - 0.00 - 15.00 pH	
Scaling end	0.00 - 16.00 pH	
At calibration	Moving Frozen Safe value	
In case of error (output signal, of the controller in case of error)	0/4 mA / 0 V 20 mA / 10 V Frozen Safety value	
Hold mode (output signal, of the controller in Hold mode)	Frozen Safety value Standard mode 0/4 mA / 0 V 20 mA / 10 V	
Safety value	0.0 - 20.0 mA	
Simulation	Off On	
Simulation value	Off 0.0 - 20.0 mA	

18 Appendix

Parameter	Selection / value range Factory setting	New setting
Interface		
Modbus address	1 - 254	
Baud rate	9600 19200 38400	
Parity	None Even Odd	
Stop bits	1 2	
Profibus address	0 - 99	
EEPROM marking	Off On	
Wash timer		
Cycle time	0.0 - 240.0 hours (0.0 = Wash contact is not active)	
Wash time	1 - 60 - 1800 seconds	
Datalogger		
Storage interval	1 - 60 - 300 seconds	
Channels 1 to 4	No signal Main value (standard for channel 1) Not comp. Main value Temperature (standard for channel 2) Option input 1 Option input 1 not compensated Option input 2 Option input 2 not compensated Option input 3 Option input 3 not compensated Math 1 Math 2 Differential signal Flow rate Partial quantity Total quantity Output controller 1 (standard for channel 3) Output controller 2 (standard for channel 4) Setpoint 1 controller 1 Setpoint 2 controller 1 Setpoint 1 controller 2 Setpoint 2 controller 2	
Date year	20xx	
Date month	1 - 12	
Date day	1 - 31	
Time hour	0 - 24	
Time minute	0 - 59	
Time second	0 - 59	

Parameter	Selection / value range Factory setting	New setting
Display		
Lighting	On With operation	
Display of measured value	Standard Tendency Bargraph Trend chart Large display 3 measured values Time	
Display Top / Center / Bottom	No signal Main value (standard for "Top") Not comp. Main value Temperature (standard for "Center" and "Bottom") Option input 1 Option input 1 not compensated Option input 2 Option input 2 not compensated Option input 3 Option input 3 not compensated Math 1 Math 2 Differential signal Flow rate Partial quantity Total quantity Output controller 1 Output controller 2 Setpoint 1 controller 1 Setpoint 2 controller 1 Setpoint 1 controller 2 Setpoint 2 controller 2	
Operating timeout	0 - 1 - 10 minutes (0 = operating timeout is turned off)	
Scaling start	-2.00 - 0.00 - 15.00 pH	
Scaling end	0.00 - 16.00 pH	

18 Appendix

Parameter	Selection / value range Factory setting	New setting
Signal source	Main value Not comp. Main value Temperature Option input 1 Option input 1 not compensated Option input 2 Option input 2 not compensated Option input 3 Option input 3 not compensated Math 1 Math 2 Differential signal Flow rate Partial quantity Total quantity	
Temperature unit	°C °F	
LCD inverse	Off On	
Contrast	0 - 10 - 20	



JUMO GmbH & Co. KG

Street address:
Moritz-Juchheim-Straße 1
36039 Fulda, Germany
Delivery address:
Mackenrodtstraße 14
36039 Fulda, Germany
Postal address:
36035 Fulda, Germany
Phone: +49 661 6003-0
Fax: +49 661 6003-607
E-mail: mail@jumo.net
Internet: www.jumo.net

JUMO Instrument Co. Ltd.

JUMO House
Temple Bank, Riverway
Harlow - Essex CM20 2DY, UK
Phone: +44 1279 63 55 33
Fax: +44 1279 63 52 62
E-mail: sales@jumo.co.uk
Internet: www.jumo.co.uk

JUMO Process Control, Inc.

8 Technology Boulevard
Canastota, NY 13032, USA
Phone: 315-697-JUMO
1-800-554-JUMO
Fax: 315-697-5867
E-mail: info@jumo.us
Internet: www.jumo.us